


FOR TYPICAL REMOTE CONTROL DETAILS, SEE DOCUMENT **RWS102**

TRANSFORMER TAPPING OPTIONS	
Tap	Nominal 50/60Hz
TYPE 1	
W	220/230
X	380/400
Y	400,415/420
Z	440/460
FUSE FS 1=250mA ANTI-SURGE	
TYPE 2	
W	346/380
X	480/500
Y	240/240
Z	550/575
FUSE FS 1=250mA ANTI-SURGE	
TYPE 3	
X	660/660-690
Y	690/-
FUSE FS 1=150mA ANTI-SURGE	

REFER TO SHEET 2 FOR NOTES & OPTION PCB'S IF FITTED



Iss	Date	Chkd	Revision Details
1	280915	JC1	First Issue.


**www.rotork.com**

ROTORK CONTROLS LTD  
BATH, BA1 3JQ  
ENGLAND  
Tel:01225-733200


ROTORK CONTROLS INC  
ROCHESTER  
NY 14624, USA  
Tel:585-247-2304

IQ + FOLOMATIC + CPT + PAKSCAN + INDICATION RELAYS S-S8		Circuit Diagram Number		Issue No	Sheet
		<b>103K2010</b>		<b>1</b>	<b>1</b>
B1	C1	B2	C2	B1	C1
M1	V1				
Drawn by: PJW Date : 280915 Base WD: 103K2010 Job No : -- MI No : --					


# SLOT A



# SLOT B



# SLOT C



## NOTES

### 1.FUSES:

- PS1 is a self-resetting fuse.
- Refer to publication PUB002-039 for approved fuses FS1 and FS2.
- Actuator rated voltage specified on nameplate. Voltage tolerance +/-10%, applies for rated torque performance; duty cycle is not guaranteed.

### 2.REMOTE CONTROL:

- For typical remote control circuits refer to:
  - RWS indicated or PUB002-041.
  - For DC and AC control, connect -ve/0V to terminal 36.
  - (For negative switch / positive common, refer to RWS indicated).
  - Control signal threshold voltages:
    - DC: "on" ≥16Vdc / "off" ≤8Vdc, max 60Vdc.
    - AC: "on" ≥60Vac / "off" ≤40Vac, max 120Vac.
  - Control signal duration to be 300ms minimum.
  - Maximum current drawn from remote control signals is:
    - 8mA at 24Vdc or 12mA at 120Vac.
  - Supply provided on terminals 4 & 5:
    - Intended for remote control.
    - Max external load 5W at 24Vdc / 5VA at 120Vac

### 3.INDICATION:

- For typical position, status and alarm indication see PUB002-041.
- “S” contacts are user configurable and are shown in their default setting.
- Refer to PUB002-040 for functions and configuration instructions.
- Monitor Relay indicates actuator availability for remote control (shown “unavailable”). It can be configured to exclude local/remote selection.
- Refer to PUB002-040 for monitored functions and configuration instructions.
- Voltage applied to indication contacts must not exceed 150Vac
- Individual Switch current must not exceed 3.5A inductive, 5A resistive and no more than 8A in total for all 4 contacts.

### 4.BATTERY:

- Battery maintains local and remote “S” contact indication only.
- Refer to installation manual for approved replacement battery types.