




The **SKILMATIC**<sup>®</sup>  
Range




**rotork**<sup>®</sup>

# Insight2

Loading ---

**Redefining Flow Control**

Rotork Controls Ltd © 2014



Redefining Flow Control

<b>1.0 INTRODUCTION</b> .....	<b>7</b>
1.1 INSTALLING INSIGHT 2 .....	7
1.2 UNINSTALLING INSIGHT 2 .....	7
1.3 UPDATING INSIGHT 2 .....	7
<b>2.0 LOGGING IN</b> .....	<b>8</b>
2.1 LOGIN SCREEN .....	8
2.2 USER LEVELS .....	8
2.2.1 Viewer.....	8
2.2.2 User .....	9
2.2.3 Service_Engineer .....	9
2.2.4 Administrator .....	9
<b>3.0 HOME SCREEN</b> .....	<b>10</b>
3.1 LAYOUT .....	11
3.2 MENU BAR.....	12
3.2.1 File.....	12
3.2.2 Connection .....	15
3.2.3 Security.....	15
3.2.4 Tools .....	16
3.2.5 Help .....	17
3.3 ICON BAR .....	18
3.3.1 Open Configuration .....	18
3.3.2 Save As.....	18
3.3.3 Save.....	18
3.3.4 Print.....	18
3.3.5. Send Configuration .....	18
3.3.6 Read Configuration.....	18
3.3.7 Discard.....	18
3.4 SIDE PANEL.....	19
3.4.1 Offline.....	19
3.4.2 Bluetooth .....	19
3.5 RANGE PANEL .....	20
3.6 PRESENTATION WINDOW.....	21
3.7 STATUS BAR.....	21
3.7.1 Connection Status.....	21
3.7.2 Actuator Login Level .....	21
3.7.3 Insight 2 Login Level .....	21
<b>4.0 CONNECTING AND DISCONNECTING DEVICES</b> .....	<b>22</b>
4.1 SEARCHING FOR DEVICES.....	22
4.2 CONNECTING TO AN ACTUATOR .....	23
4.3 CONNECTING TO A BLUETOOTH SETTING TOOL .....	23
4.4 DISCONNECTING FROM DEVICES.....	23
<b>5. CVA</b> .....	<b>24</b>
5.1 CVQ/CVL DEVICE INFORMATION .....	25
5.1.1 Valve Tag .....	25
5.1.2 CVA/CVQ Type.....	25
5.1.3 CVA Main PCB Software Version .....	25
5.1.4 Manufacturing Data .....	25
5.1.5 Service Notes.....	25
5.1.6 Date of Manufacture .....	25
5.1.7 CVA Hardware.....	25

5.1.8 Main Controller Serial No.....	25
5.1.9 UPS Controller Serial No.....	25
5.1.10 Position Sensor Serial No.....	25
5.1.11 Motor Sensor Serial No.....	25
5.1.12 Force Sensor Serial No.....	26
5.1.13 User Interface Serial No.....	26
5.2 ACTUATOR CONFIGURATION - CVA VALVE SETUP .....	26
5.2.1 Valve Action Settings.....	26
5.2.2 MOVTag.....	26
5.2.3 Valve Action Settings.....	26
5.2.4 Input / Output Setup.....	27
5.3 ADVANCED SETTINGS 1 .....	27
5.3.1 Tight Shut Off.....	27
5.3.2 Obstruction Action Active .....	27
5.3.3 Obstruction Values Setup.....	28
5.3.4 Manual Test Knob Setup.....	28
5.4 ADVANCED SETTINGS 2.....	28
5.4.1 Travel Alarm Thresholds .....	28
5.4.2 Bumpless Transfer Setup.....	28
5.5 UPS CONFIGURATION AND STATUS .....	29
5.5.1 UPS Configuration .....	29
5.5.2 UPS Status Information.....	30
5.6 CVA STATUS.....	30
5.6.1 Actuator Position (%).....	30
5.6.2 Actuator Torque (%) .....	30
5.6.3 Analogue Demand Input (mA).....	30
5.6.4 Analogue Position Feedback (mA).....	30
5.6.5 ESD Input Status.....	30
5.7 CVA MAIN DATALOGGER.....	31
5.7.1 Event Logger .....	31
5.7.2 CVA Dwell Log .....	34
5.7.3 CVA Torque Logs.....	34
5.7.4 CVA Movement Log .....	35
<b>6.0 IQ3 SETTINGS .....</b>	<b>36</b>
6.1 ACTUATOR INFORMATION .....	38
6.1.1 Actuator User Information.....	38
6.1.2 Actuator Serial Numbers.....	38
6.1.3 Actuator Manufacturing Information.....	39
6.2 ACTUATOR NAME PLATE .....	40
6.2.1 Actuator Name Plate Info .....	40
6.2.2 Valve Manufacturing Information.....	41
6.2.3 Gearbox Manufacturing Information .....	42
6.3 ACTUATOR SETTINGS.....	43
6.3.1 Basic Settings .....	43
6.3.2 ESD Configuration.....	44
6.3.3 REMOTE CONFIGURATION .....	45
6.3.4 Local Configuration.....	45
6.3.5 Special Mode Configuration.....	46
6.4 TORQUE SETTINGS.....	47
6.4.1 Current Torque Readings .....	47
6.4.2 Actuator Torque Settings.....	47
6.4.3 Torque Advanced Settings.....	47
6.4.4 Torque Profile Settings.....	48
6.5 POWER SETTINGS.....	48
6.5.1 Power Type.....	48
6.6 DIGITAL INPUT SETTINGS.....	49

6.6.1 DI Function.....	49
6.6.2 DI Input Type.....	49
6.7 PARTIAL STROKE SETTINGS.....	50
6.7.1 Partial Stroke Enable.....	50
6.7.2 Partial Stroke Initial Position.....	50
6.7.3 Partial Stroke Position (%).....	50
6.7.4 Partial Stroke Time to Position (sec).....	50
6.7.5 Partial Stroke Time to Limit (sec).....	50
6.8 RELAY SETTINGS.....	51
6.8.1 Monitor Relay Function.....	51
6.8.2 Relay Settings.....	52
6.9 OPTION CONTROL.....	53
6.9.1 Option Source Selection.....	53
6.9.2 Auxiliary Mask Configuration.....	54
6.9.3 Option 1-4 Configuration.....	54
6.10 CONTROL SETTINGS.....	55
6.10.1 Position Settings.....	55
6.10.2 Interrupter Timer.....	56
6.11 UI SETTINGS.....	57
6.11.1 Indication Configuration.....	57
6.11.2 Communication Configuration.....	58
6.12 LANGUAGE SETTINGS.....	58
6.12.1 Display Language.....	58
6.12.2 Language Option Details.....	59
6.13 NAMUR SETTINGS.....	59
6.13.1 Namur Status.....	59
6.13.2 Namur Mask Settings (All groups).....	60
6.14 ANALOGUE CONTROL/CPT/CTT/AIO OPTION.....	60
6.15 EXTRA RELAYS S5-S8.....	60
<b>7.0 IQ3 DATA LOGGER.....</b>	<b>61</b>
7.1 EVENT LOGGER.....	62
7.1.1 Time Line.....	62
7.1.2 Trace View.....	63
7.1.3 List View.....	64
7.2 TORQUE PROFILE.....	65
7.3 TORQUE LIMIT PROFILES.....	65
7.4 TORQUE REFERENCE PROFILE.....	66
7.5 TORQUE REFERENCE LIMIT PROFILES.....	67
7.6 STARTS LOG.....	68
7.7 MOVEMENT LOG.....	69
7.8 CURRENT PARTIAL STROKE PROFILE.....	70
7.9 VIBRATION TREND LOG.....	71
7.10 BATTERY VOLTAGE AND TEMPERATURE TREND LOG.....	72
7.10.1 Battery Voltage Trend.....	72
7.10.2 Temperature Trend.....	72
7.11 MOTOR STARTS AND OUTPUT TURNS TREND LOG.....	73
7.12 MISCELLANEOUS DATALOG DATA.....	74
7.12.1 Motor Related Data.....	74
7.12.2 Power Related Data.....	74
7.12.3 Limit Related Data.....	75
7.12.4 Environmental Related Data.....	75
<b>8.0 EH PRO AND SI PRO SCREENS.....</b>	<b>76</b>
8.1 BASIC SETTINGS.....	78
8.1.1 Valve Tag.....	78
8.1.2 Close Action.....	78

8.1.3	Open Action.....	78
8.1.4	Close Pressure (Limit) (%).....	78
8.1.5	Close Pressure (Mid) (%).....	78
8.1.6	Open Pressure (Limit) (%).....	78
8.1.7	Open Pressure (Mid) (%).....	78
8.1.8	Closed Limit.....	78
8.1.0	Open Limit.....	78
8.2	CONTACT RELAYS.....	79
8.2.1	Contact – Function.....	79
8.2.2	Contact – Value.....	79
8.2.3	Contact – Form.....	79
8.3	GENERAL SETTINGS.....	80
8.3.1	Remote Select.....	80
8.3.2	Configure Local Controls.....	80
8.3.3	Low Power Mode.....	80
8.3.4	Closed LED Colour.....	80
8.4	DIGITAL CONTROL.....	81
8.4.1	Remote Priority.....	81
8.4.2	Hold Position.....	81
8.4.3	Position Hysteresis.....	81
8.4.4	Over Pressure Hysteresis.....	81
8.4.5	Under Pressure Hysteresis.....	81
8.5	ESD/PARTIAL STROKE.....	82
8.5.1	ESD.....	82
8.5.2	Partial Stroke.....	83
8.5.3	Reference Partial Stroke Test Recorded Values.....	83
8.6	ANALOGUE CONTROL.....	84
8.6.1	Analogue Control.....	84
8.6.2	Flow Characterisation.....	85
8.7	INTERRUPTER TIMER.....	86
8.7.1	Interrupter Timer.....	86
8.7.2	Interrupter Timer Direction.....	86
8.7.3	Interrupter Timer Start (%).....	86
8.7.4	Interrupter Timer Stop (%).....	86
8.7.5	Interrupter Timer Interval.....	86
8.7.6	Interrupter Timer On Time.....	86
8.7.7	Interrupter Timer Off Time.....	86
8.7.8	Interrupter Timer with ESD Enabled.....	86
8.8	ACTUATOR STATISTICS.....	87
8.8.1	Number of Times Open Limit Reached.....	87
8.8.2	Number of Times Close Limit Reached.....	87
8.8.3	Time Spent Moving Open (sec).....	87
8.8.4	Time Spent Moving Closed (sec).....	87
8.8.5	Number of ESD Events.....	87
8.8.6	Number of Motor Starts.....	87
8.8.7	Number of Accumulator Recharges.....	87
<b>9.0</b>	<b>BLUETOOTH SETTING TOOL SCREENS.....</b>	<b>88</b>
9.1	BTST INFORMATION.....	88
9.1.1	Firmware Version.....	88
9.1.2	Battery Status (mV).....	88
9.1.3	Number of Files.....	88
9.1.4	Free Space on the BTST (Bytes).....	88
9.1.5	Flash Memory size on BTST (Bytes).....	88
9.2	CVA.....	88
9.3	IQ2.....	89
9.4	EHP.....	89

9.5 IQ3 .....	89
9.6 SIP .....	89
9.7 MISSIONS .....	89
9.7.1 <i>Create Missions</i> .....	89
9.7.2 <i>Custom Mission</i> .....	92
9.7.3 <i>Review/Edit Mission</i> .....	93
9.7.4 <i>Delete Mission</i> .....	93
9.7.5 <i>Delete All Missions</i> .....	93
9.7.6 <i>Format BST</i> .....	94

## 1.0 Introduction

### 1.1 Installing Insight 2

### 1.2 Uninstalling Insight 2

### 1.3 Updating Insight 2

#### 1.1 Installing Insight 2

The Insight 2 program can be downloaded from the Insight 2 download page on:

[www.rotork.com/en/support/index/downloads](http://www.rotork.com/en/support/index/downloads)

**You will be required to Log in with your Rotork Internet Portal Account to access this page.**

*(To register for a free Rotork Internet Portal Account click register and fill out the application form)*

On the IQ Insight 2 download page you can view information about the software and the minimum PC operating requirements. It is worth noting down the program access passwords for future use. When you are satisfied that your machine is compatible with Insight 2, click Download IQ-Insight 2 Software for PC. This will begin the software package download for the latest version of Insight 2.


Once the download is complete, extract the install package to a user specified save location. Open the **Setup.exe** file to load the installation wizard and begin the program install process. Follow the on-screen prompts to install Insight 2.

#### 1.2 Uninstalling Insight 2

To uninstall Insight 2 use the Uninstall Insight 2 start menu shortcut or proceed through the standard Windows software management feature. This can be found within the control panel.

**For XP users use the “Add/Remove Programs” feature.**

**For Vista and 7 users use the “Uninstall a program” feature.**



Select Insight 2 from the program list and select uninstall. Follow the onscreen wizard to complete the removal of Insight 2.

#### 1.3 Updating Insight 2

Insight 2 will be updated periodically to add new features and increased compatibility with new Rotork actuators. To update your copy of Insight 2 please follow instructions detailed on the download page of the Rotork website [www.rotork.com/en/support/index/downloads](http://www.rotork.com/en/support/index/downloads).

## 2.0 Logging In


### 2.1 Login Screen

### 2.2 User Levels

- 2.2.1 Viewer
- 2.2.2 User
- 2.2.3 Service Engineer
- 2.2.4 Administrator

### 2.1 Login Screen


Below is the login screen for Insight 2.



This screen provides the user with four access levels on a drop down menu that require the corresponding passwords to be entered. The check box in the bottom left allows Insight 2 to remember your login details for easy access to the program in the future.

### 2.2 User Levels

The Privilege Level drop down menu presents 4 selections.



This selection will determine the available access levels visible when connecting to a Rotork Bluetooth device.

#### 2.2.1 Viewer

As a Viewer you can connect to any Bluetooth equipped Rotork device. These include: IQ3, CVA, EH Pro, SI Pro and Rotork Bluetooth Setting Tool Pro. Viewer level prevents operators from modifying the settings of an actuator.

Default Insight 2 Viewer Password: **ROTORK**



### 2.2.2 User

As a User you can perform all the tasks of a Viewer with the ability to modify setting values. An actuator User login allows you to change some settings within the actuators configuration.

Default Insight 2 User Password: **ROTORK**

### 2.2.3 Service Engineer

This login is reserved for the use of Rotork Service Engineers.

### 2.2.4 Administrator

This Login is reserved for the use of Rotork Engineers.

## **3.0 Home Screen**

### **3.1 Layout**

### **3.2 Menu Bar**

- 3.2.1 File
- 3.2.2 Connection
- 3.2.3 Security
- 3.2.4 Tools
- 3.2.5 Help

### **3.3 Icon Bar**

- 3.3.1 Open Configuration
- 3.3.2 Save As
- 3.3.3 Save
- 3.3.4 Print
- 3.3.5 Send
- 3.3.6 Receive Configuration
- 3.3.7 Discard

### **3.4 Side Panel**

- 3.4.1 Offline
- 3.4.2 Bluetooth

### **3.5 Range Panel**


### **3.6 Presentation Window**

### **3.7 Status Bar**

- 3.7.1 Connection Status
- 3.7.2 Actuator Login level
- 3.7.3 Insight 2 Login Level


### 3.1 Layout

For the purpose of this manual the main Insight 2 screen has been split into six areas as shown below.




Description	Colour
Menu Bar	Blue
Icon bar	Orange
Side Panel	Purple
Range Panel	Yellow
Presentation Window	Green
Status Bar	Red


## 3.2 Menu Bar





### 3.2.1 File



### New Configuration




Use this function to create a new default configuration for a compatible Rotork product. There are 5 types of actuator that can be configured with Insight 2. The name and save location of the configuration can be modified appropriately if required.




Once "Ok" is selected the loading screen will appear as Insight 2 prepares the new configuration. This will appear in the Offline section of the side menu (for side menu information see section 3.4.1) under the correct actuator type.

**NOTE: using this function on a live actuator will clear any previous configuration. Ensure a copy of the existing configuration is saved before using this feature.**

## Open



## Configuration




The configuration option allows the user to open saved configuration files. Opened files will be shown in the Offline section of the Side menu under the relevant actuator type.

## Firmware

This function is only available for Rotork Service Engineers and Service centres.

## Save



When a configuration in the Offline section is changed the user can save those changes.

### **Save As**

This function enables the user to save configuration files from the Offline or Online sections of the side menu to a directory on the PC. These will be available for future offline use. This feature is to be used for saving the configuration and datalogger files in the format to be read by Insight 2. For other formats use the export feature.

### **Export**

#### **Configuration**

This exports the current actuator configuration as either a Comma Separated Value (.csv) or a Text file (.txt)


#### **Configuration and DataLogs**

This exports the current actuator configuration and data log file as either a Comma Separated Value (.csv) or a Text file (.txt). The data log must be viewed within Insight 2 prior to exporting the data.

### **Exit**

The Exit function will close Insight 2 and disconnect from any active Bluetooth device.

### 3.2.2 Connection



#### *Discover Devices*


This initialises a search for all Bluetooth enabled actuators\* and setting tools within the Bluetooth adaptor range (setting tools can only be found whilst in slave mode, refer to the Bluetooth Setting Tool manual for more information).

#### *Recent Discovered Devices*

This provides a list of previously connected devices that the operator can connect to without requiring a Bluetooth search\*.

\*Actuators must be in a Bluetooth visible mode and within range of the Bluetooth adapter to be discovered with Insight 2.


### 3.2.3 Security



#### **Change Privilege**

This enables the user to change their privilege level within Insight 2 by re-opening the Login screen (see section 2 Logging In).

#### **Change Application Password**




This function enables the current user to change the Insight 2 login passwords for the current privilege level and any lower privilege level.

## Change Actuator Password

This function is reserved for Rotork Service Engineer use only.

### 3.2.4 Tools



## Sensor Calibration

This function is reserved for Rotork Service Engineer use only.


## Zero Thrust

This function is reserved for Rotork Service Engineer use only.

## CP Chat


This function is reserved for Rotork Service Engineer use only.

## Unit Setting



The units displayed within Insight 2 can be set to Metric or Imperial to suit various global markets (**Insight 2 default = Metric**).

## Install Actuator Devices




This function enables Insight 2 to be updated using a compressed ADF file package provided by Rotork. All future updates will be supported via this feature to ensure reliable compatibility with the continually expanding Rotork product offering.

To download the latest ADF file please visit the Insight 2 download page:


<http://www.rotork.com/customers/index/iqinsight2>.

Save the ADF file to an accessible PC directory and then browse to the file through the Install Actuator Devices function.






On successful installation of the update you will be requested to restart Insight 2.



### 3.2.5 Help



#### View Help

##### Insight 2 Help

This help file is currently under construction. Future releases will include information about various Insight 2 functions.


##### Actuator Help

This help file is currently under construction. Future releases will include information about various Rotork actuator functions relevant to the connected actuator type.


##### About Us

Shows the current version number of the Insight 2 program and contains a brief description about the purpose of Insight 2.


## 3.3 Icon Bar




### 3.3.1 Open Configuration

 This allows the user to open a saved Configuration file (.icf) from a PC directory in the Offline section of the Side panel.


### 3.3.2 Save As

 This function enables configuration files from the Offline or Online sections of the side menu to be saved in a PC directory.


### 3.3.3 Save

 When a configuration is open in the Offline Section, this function enables the user to save any modifications to the settings.


### 3.3.4 Print

 This will print the current information in the presentation window as it is shown on the screen (only available when actuator information is displayed within the window).


### 3.3.5. Send Configuration

 This function will send all visible configuration changes to the connected actuator. Send Configuration will only be possible when connected to a Bluetooth device.


### 3.3.6 Read Configuration

 This function will read a device's current configuration. Read Configuration will only be possible when connected to a Bluetooth device.

### 3.3.7 Discard

 Removes any unsaved configuration changes (highlighted yellow) displayed within the presentation window.


### 3.4 Side Panel



#### 3.4.1 Offline

##### Actuators

All offline actuator configurations opened in Insight 2 are stored for the session under their respective actuator type (see Fig 1). Configurations can be edited and viewed (with the correct privilege level) from the expanded menu (See fig 2).




##### Firmware

This function is reserved for Rotork Service Engineer use only.

#### 3.4.2 Bluetooth


##### Actuators

All actuators that have been found by after a Bluetooth search (see 1.0 and 4.0) will be visible here. The expanded menu can only be accessed once a connection to the device has been established.




### Bluetooth Setting Tool

All visible Bluetooth Setting Tools currently in slave mode and available for connection (See Bluetooth Setting Tool Manual for details) will be visible in this section. The expanded menu can only be accessed once a connection to the Bluetooth Setting Tool has been established.



### 3.5 Range Panel

The Range Panel will indicate which actuator range the current configuration or data log belongs to. If the device is currently connected through Insight 2 the serial number and valve tag will also be displayed.



### 3.6 Presentation Window

The presentation window is where all configuration and data log information is displayed. Any setting entries that are shaded grey are non-editable at the current privilege level.

Actuator Information	
<b>Actuator User Information</b>	
Valve label	Test IQ3
<b>Actuator Serial Numbers</b>	
Actuator	2624431501
Main Controller	1226BX0160026803=107711
Position Sensor	1226BX0160022501=103311
Torque Sensor	2612493022006=101671
User Interface	1226BX0160003704=101131
Option 1	2112BX1820007601=108661
Option 2	
Option 3	
Option 4	
Power Board	1228BX0160048102=102251
DC Power Board (if fitted)	
Solid State Starter Board (if fitted)	
<b>Actuator Manufacturing Information</b>	
Date of Manufacture	20120829
Service Commission Date	28/02/12
Service Inspection Date	
Factory Acceptance Test Date	
Wiring Diagram	100K2000

### 3.7 Status Bar

Current status of actuator connection, actuator privilege level and Insight 2 privilege level are displayed at all times within the Insight 2 window.



#### 3.7.1 Connection Status

Connection status for Insight 2 is visible in the left portion of the status bar. An online connection will show the actuator Bluetooth tag or Bluetooth Setting Tool tag and the connection method. If a Bluetooth connection is not currently active an offline status will be displayed.




#### 3.7.2 Actuator Login Level

Current actuator login level is shown in the middle portion of the status bar. There are three levels available: Viewer, User and Engineer.



#### 3.7.3 Insight 2 Login Level

The current privilege level access for Insight 2 is displayed in the right portion of the status bar. To change access level, click on this part of the status bar or use the change privilege level option (See 3.2.3.1).



## 4.0 Connecting and Disconnecting Devices

### 4.1 Searching for Devices

### 4.2 Connecting to an Actuator


### 4.3 Connecting to a Bluetooth Setting Tool

### 4.4 Disconnecting from Devices

## 4.1 Searching for Devices

Use the Discover Devices function (as detailed in 3.2). This will begin a search for all Rotork Bluetooth enabled devices and setting tools within range of the Bluetooth adapter.


Please note only actuators with a Bluetooth Security setting of Medium or Low are visible within Insight 2. Bluetooth setting Tools have to be in slave mode to be found by Insight 2 (refer to the Bluetooth Setting Tool Manual for information on how to activate Slave Mode).




Once the search is complete, all actuators found will be displayed in the expanded menu under the relevant range heading. Each unit will be identified by Serial Number and Bluetooth Friendly Tag. Bluetooth Setting Tools will be identified by the acronym BST and the Bluetooth MAC address.

## 4.2 Connecting to an Actuator

To connect to an actuator, double click on the actuator name or right click on the actuator name and click Connect.



If you try to connect to more than one actuator the warning box below will be shown.




## 4.3 Connecting to a Bluetooth Setting Tool

Connecting to a Bluetooth Setting Tool is performed in the same manner as connecting to an actuator. Upon connection with Insight 2 the Setting Tool's Enter key will rapidly flash blue indicating a connection has been established. The connection privilege Level of the Bluetooth Setting Tool is dictated by the current Insight 2 Privilege Level.

## 4.4 Disconnecting from Devices

You can disconnect from a device by right clicking the device and selecting Disconnect from the drop down menu, this is applicable to all Bluetooth devices.



## **5. CVA**

### **5.1 CVQ/CVL Device Information**

- 5.1.1 Valve Tag
- 5.1.2 CVA/CVQ Type
- 5.1.3 CVA Main PCB Software Version
- 5.1.4 Manufacturing Data
- 5.1.5 Service Notes
- 5.1.6 Date of Manufacture
- 5.1.7 CVA Hardware
- 5.1.8 Main Controller Serial No.
- 5.1.9 UPS Controller Serial No.
- 5.1.10 Position Sensor Serial No
- 5.1.11 Motor Sensor Serial No.
- 5.1.12 Force Sensor Serial No.
- 5.1.13 User Interface Serial No.

### **5.2 Actuator Configuration - CVA Valve Setup**

- 5.2.1 Valve Action Settings
- 5.2.2 MOVTag
- 5.2.3 Valve Action Settings
- 5.2.4 Input / Output Setup

### **5.3 Advanced Settings 1**

- 5.3.1 Tight Shut Off
- 5.3.2 Obstruction Action Active
- 5.3.3 Obstruction Values Setup
- 5.3.4 Manual Test Knob Setup
- 5.3.5 CVA Status Relay Setup

### **5.4 Advanced Settings 2**

- 5.4.1 Travel Alarm Thresholds
- 5.4.2 Bumpless Transfer Setup
- 5.4.3 Manual Test Knob Setup
- 5.4.4 CVA Status Relay Setup
- 5.4.5 Travel Alarm Thresholds
- 5.4.6 Bumpless Transfer Setup

### **5.5 UPS Configuration and Status**

- 5.5.1 UPS Configuration
- 5.5.2 UPS Status Information

### **5.6 CVA Status**

- 5.6.1 Actuator Position (%)
- 5.6.2 Actuator Torque/Thrust (%)
- 5.6.3 Analogue Demand Input (mA)
- 5.6.4 Analogue Position Feedback (mA)
- 5.6.5 ESD Input Status

### **5.7 CVA Data logger**



- 5.7.1 Event Log
- 5.7.2 Dwell Log
- 5.7.3 Torque/Thrust Logs
- 5.7.4 Movement Log

## 5.1 CVQ/CVL Device Information

**Please note that CVA actuators should be configured using dedicated Enlight support software. This is available to download free of charge from [www.rotork.com](http://www.rotork.com).**

### 5.1.1 Valve Tag

This is a user defined name for the actuator consisting of up to 32 alpha-numeric or symbolic characters. It is normally used by operators to specify a unique tag based on location or a description of the actuator. This setting is linked directly to the MOVTag in the CVA Valve Setup Menu (See Section 5.2.2).

### 5.1.2 CVA/CVQ Type

This displays the size of the actuator, along with any options fitted. Rotork Service Engineer use only.

### 5.1.3 CVA Main PCB Software Version

Shows the current Main PCB software version in the actuator. Rotork Service Engineer use only.

### 5.1.4 Manufacturing Data

Shows the manufacturing data for the actuator. Rotork Service Engineer use only.

### 5.1.5 Service Notes

This is where service notes can be entered and stored for future reference. This field accepts up to 64 characters. Rotork Service Engineer use only.

### 5.1.6 Date of Manufacture

Shows the date of manufacture in the format YYYY/MM/DD. Rotork Service Engineer use only.

### 5.1.7 CVA Hardware

Shows the current CVA Hardware Number. Rotork Service Engineer use only.

### 5.1.8 Main Controller Serial No.

This is where the Main Controller serial number can be entered and viewed. Rotork Service Engineer use only.

### 5.1.9 UPS Controller Serial No.

This is where the UPS Controller serial number can be entered and viewed. Rotork Service Engineer use only.

### 5.1.10 Position Sensor Serial No.

This is where the Position Sensor serial number can be entered and viewed. Rotork Service Engineer use only.

### 5.1.11 Motor Sensor Serial No.

This is where the Motor Sensor serial number can be entered and viewed. Rotork Service Engineer use only.

### 5.1.12 Force Sensor Serial No.

This is where the Force Sensor serial number can be entered and viewed. Rotork Service Engineer use only.

### 5.1.13 User Interface Serial No.

This is where the User Interface serial number can be entered and viewed. Rotork Service Engineer use only.

## 5.2 Actuator Configuration - CVA Valve Setup

### CVA Valve Setup

Valve Action Settings	
Valve Open Torque Setting (%)	40
Valve Close Torque Settings (%)	40
MOV Tag	
Valve Tag	Rotork Control Valve Actuator
Valve Action Settings	
Shaft Action	<input checked="" type="radio"/> Clockwise to Close <input type="radio"/> Clockwise to Open
Open Stop Action	<input checked="" type="radio"/> Limit <input type="radio"/> Torque
Close Stop Action	<input type="radio"/> Limit <input checked="" type="radio"/> Torque
Input / Output Setup	
Demand Deadband (%)	0.1
Demand Damping Clockwise(secs)	0
Demand Damping Anti-Clockwise(secs)	0
4-20mA Output	<input checked="" type="radio"/> Valve Position <input type="radio"/> Valve Torque

### 5.2.1 Valve Action Settings

#### *Valve Open Torque/Thrust Setting (%)*

The slider sets the percentage of rated torque/thrust the actuator will be limited to during operation in the open direction. This is adjustable between 40% and 100%.

#### *Valve Close Torque/Thrust Setting (%)*

The slider sets the percentage of rated torque/thrust the actuator will be limited to during operation in the closed direction. This is adjustable between 40% and 100%.

### 5.2.2 MOVTag

#### *Valve Tag*

This is a user defined name for the actuator consisting of up to 32 alpha-numeric or symbolic characters. It is normally used by operators to specify a unique tag based on location or a description of the actuator. This setting is linked directly to the Valve Tag in the CVQ/CVL Device Information Menu (See Section 5.1.1).

### 5.2.3 Valve Action Settings

#### *Shaft Action*

Specify the output direction of the actuator. CVL actuators can be configured for extend to close or extend to open operation. CVQ actuators can be configured for clockwise to close or anti-clockwise to close.

### Open Stop Action

The actuator can be set to stop in the open direction when it reaches the open position limit or when it reaches the defined open torque/thrust setting value (see section 5.2.1).

### Close Stop Action

The actuator can be set to stop in the close direction when it reaches the close position limit or when it reaches the defined close torque/thrust setting value (see section 5.2.1).

## 5.2.4 Input / Output Setup

### Demand Deadband (%)

The demand deadband sets the expected positioning accuracy of the actuator and is dependent on various factors including actuator output speed, number of turns and valve torque. The actuator will run until it reaches a position within the demanded deadband. The actuator will not restart until the demanded position exceeds the extent of the deadband.

### Demand Damping Clockwise (secs)

Setting a value greater than 0 will apply a delay in the clockwise direction, temporarily inhibiting movement when a change to the set point signal occurs.

### Demand Damping Anti-Clockwise (secs)

Setting a value greater than 0 will apply a delay in the anti-clockwise direction, temporarily inhibiting movement when a change to the set point signal occurs.

### 4-20mA Output

Specify whether the 4-20mA output provides feedback for Valve Position or Valve Torque/Thrust.

## 5.3 Advanced Settings 1

### Advanced Settings 1

Tight Shut Off	
Valve Tight Shut Off Open Position (%)	99.5
Valve Tight Shut Off Closed Position (%)	0
Obstruction Action Setup	
Obstruction Action Active	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
Obstruction Values Setup	
Backoff Distance (%)	10
Backoff Time (sec)	1
Manual Test Knob Setup	
Manual Test Knob Active	Enabled

### 5.3.1 Tight Shut Off

#### Valve tight shut off Open position (%)

This is the minimum position required to fully open (tight shut off) the valve.

#### Valve tight shut off Closed position (%)

This is the maximum position required to fully close (tight shut off) the valve.

### 5.3.2 Obstruction Action Active

If enabled, the actuator will back off movement if the maximum torque/thrust is exceeded during travel. The actuator will make 3 attempts to back off and return to the set point. If disabled, the

actuator will remain stationary until a request to move in the opposite direction is received or the obstruction is removed. To set up obstruction settings see section 5.3.3.

### 5.3.3 Obstruction Values Setup

#### *Backoff Distance (%)*

The distance the actuator will back off as a percentage of total travel.

#### *Backoff Time (Sec)*

The time in seconds before a back off command is executed.

### 5.3.4 Manual Test Knob Setup

#### *Manual Test Knob Active*

Enables or disables the Manual Test knob option provided it is fitted to the actuator.

## 5.4 Advanced Settings 2

### Advanced Settings 2

Travel Alarm Thresholds	
Direction Change Threshold Distance (%)	0.25
Total Direction Changes Threshold (1000s)	10000
Total Travel Distance Threshold (%)	100
Bumpless Transfer Setup	
Bumpless Transfer Distance (%)	100
Bumpless Transfer Speed (%)	100

#### 5.4.1 Travel Alarm Thresholds

##### *Direction Change Threshold Distance (%)*

The distance the actuator must move (as a percentage of full travel) before a direction change is registered by the data logger as a start. The default setting is 0.25%.

##### *Total Direction Changes Threshold (1000s)*

This can be used to generate a Travel Alarm when a set number of direction changes have been performed by the actuator.

##### *Total Travel Distance Threshold (%)*

This can be used to generate a Travel Alarm when a set distance has been travelled by the actuator.

#### 5.4.2 Bumpless Transfer Setup

##### *Bumpless Transfer Distance (%)*

This is the percentage of position error that will reduce the actuator speed to the Bumpless Transfer Speed.

##### *Bumpless Transfer Speed (%)*

This is the speed that the actuator will revert to if the bumpless transfer distance is exceeded. It is measured as a percentage of rated maximum speed and the default setting is 40%.

## 5.5 UPS Configuration and Status

### UPS Configuration and Status

UPS Configuration	
Action on Loss of Power	Closed Limit
Position CVA Travels To On Loss of Power (%)	30
Power Failure Delay (sec)	5
Speed of Operation During UPS Action Rated (%)	100
UPS Status Information	
UPS Status Data (Raw decimal value)	35456
UPS Supply Voltage (V)	242.78
UPS Capacitor 1 Voltage (V)	1.723
UPS Capacitor 2 Voltage (V)	1.699
UPS Capacitor 3 Voltage (V)	1.635
UPS Capacitor 4 Voltage (V)	1.724
UPS Temperature Sensor value (°)	0.38
UPS Capacitor 1 Value (Farads)	291.213
UPS Capacitor 2 Value (Farads)	296.304
UPS Capacitor 3 Value (Farads)	290.495
UPS Capacitor 4 Value (Farads)	281.186
UPS Capacitor 1 Discharge Voltage (V)	1.747
UPS Capacitor 2 Discharge Voltage (V)	1.732
UPS Capacitor 3 Discharge Voltage (V)	1.732
UPS Capacitor 4 Discharge Voltage (V)	1.756
UPS Capacitor 1 End Discharge Voltage (V)	1.545
UPS Capacitor 2 End Discharge Voltage (V)	1.53
UPS Capacitor 3 End Discharge Voltage (V)	1.53
UPS Capacitor 4 End Discharge Voltage (V)	1.554
UPS Capacitor 1 Discharge Time (sec)	
UPS Capacitor 2 Discharge Time (sec)	
UPS Capacitor 3 Discharge Time (sec)	
UPS Capacitor 4 Discharge Time (sec)	

### 5.5.1 UPS Configuration

#### Action on Loss of Power

The actuator can be configured to perform four different actions on loss of power. These are:

**Closed Limit:** The actuator will move to the closed limit.

**Open Limit:** The actuator will move to the open limit.

**Stayput:** The actuator will remain at the current position (Default Setting).

**Go To Position:** The actuator will move to a pre-determined position.

#### Position CVA travels to on Loss of Power (%)

The position the actuator will travel to on Loss of power, provided the Power Loss Action is set for Go To Position. The position is a percentage of the full stroke and can be configured in increments of 0.1%.

#### Powerloss Action Delay timeout (sec)

The delay in seconds before the Power Loss Action is executed. The maximum allowable delay to guarantee a failsafe action will perform is 10 seconds.

#### Speed of Operation during UPS action rated (%)

The speed of operation during the UPS action can be adjusted as a percentage of normal operating speed.

## 5.5.2 UPS Status Information

### *UPS Status Data (Raw Decimal Value)*

For indication only, shows the raw decimal value that the UPS supplies to the actuator.

### *UPS Supply Voltage (V)*

For indication only, shows the UPS supply voltage received by the actuator.

### *UPS Capacitor Voltages (V)*

For indication only, shows the charge stored by each capacitor.

### *UPS Temperature Sensor Value (°C)*

For indication only, shows the temperature measured at the UPS.

### *UPS Capacitor Values (Farads)*

For indication only, shows the UPS capacitor values for all fitted capacitors.

### *UPS Capacitor Discharge Voltages (V)*

For indication only, shows the separate discharge voltage for all fitted capacitors.

### *UPS End Discharge Voltage (V)*

For indication only, shows the separate end discharge voltage for all fitted capacitors.

### *UPS Discharge Time (sec)*

For indication only, shows the separate discharge time for each of the fitted capacitors.

## 5.6 CVA Status

### CVA Status

Status Information	
Actuator Position (%)	44.96
Actuator Torque (%)	5.8
Analogue Demand Input (mA)	20
Analogue Position Feedback (mA)	15.596
ESD Input Status	<input checked="" type="radio"/> ESD Input not Active <input type="radio"/> ESD Input Active

### 5.6.1 Actuator Position (%)

For indication only, shows the position of the actuator as a percentage of full travel.

### 5.6.2 Actuator Torque (%)

For indication only, shows the percentage of rated torque currently measured through the actuator drive train.

### 5.6.3 Analogue Demand Input (mA)

For indication only, shows the analogue input signal being received by the actuator.

### 5.6.4 Analogue Position Feedback (mA)

For indication only, shows the output signal being transmitted by the actuator with reference to position or force (see 5.2.4).

### 5.6.5 ESD Input Status

For indication only, denotes whether the actuator ESD input is presently active or not.

## 5.7 CVA Main Datalogger

The size of the Insight 2 window can be adjusted to expand or retract the visible range on graphical screens for increased or decreased detail.

### 5.7.1 Event Logger


The Event Logger will store information related to actuator actions and condition changes. All events are date and time stamped to accurately assess the actuator operations.



The top scroll bar can be used to navigate from the first recorded event (far left) to the most recent event (far right). The recorded event number is shown with the event date and event time above the navigation bar.


#### Time Line

The Time Line display style provides the user with a visual indication of active conditions for the specific event selected with the top scroll bar. An active condition is indicated by a checked box. The dropdown menu is included to apply a filter. The Prev and Next actions buttons chronologically skip to the next recorded event for the chosen condition.




## Trace View

The trace view provides a comparison between various event triggers during each period between events. The Position (%) trace is an analogue recorded value whilst other event conditions can be configured as Digital Traces.



The top scroll bar can be used to navigate through various events. There is also an additional scroll bar within the Trace view window. This can be used to adjust the scaling of both traces for more detailed analysis.


Each digital trace can be allocated a different function by opening the associated drop down menu and selecting the required condition.





## List View

This type of display depicts the Data Log of the CVA in tabular format as a chronological series of events.




Time	Event	Position (%)
20/05/2014 14:38:11.250	Close limit	0.01
20/05/2014 14:38:11.250	Local Control in RUN	0.01
20/05/2014 14:38:11.250	Control Signal loss	0.01
20/05/2014 14:38:11.250	Moving CLOSED	0.01
20/05/2014 14:38:11.250	Moving	0.01
20/05/2014 14:39:39.500	Monitor Relay State	0
20/05/2014 14:39:39.500	Close limit	0
20/05/2014 14:39:39.500	Local Control in RUN	0
20/05/2014 14:39:39.500	Control Signal loss	0
20/05/2014 14:39:39.500	Monitor Relay State	0.02
20/05/2014 14:39:39.500	Local Control in RUN	0.02
20/05/2014 14:39:39.500	Control Signal loss	0.02
20/05/2014 14:42:37.750	Local Control in RUN	44.96
20/05/2014 14:42:37.750	Control Signal loss	44.96
20/05/2014 14:42:42.000	Open limit	99.53
20/05/2014 14:42:42.000	Local Control in RUN	99.53
20/05/2014 14:42:42.000	Control Signal loss	99.53
20/05/2014 14:42:42.000	Moving OPEN	99.53

The top slider bar can be used to navigate through all available events currently in the data log. Alternatively the scroll bar on the right side of the event information can be used to navigate events in the same fashion.

### 5.7.2 CVA Dwell Log

The Dwell Log Graph indicates the amount of time spent at each position between the limits of travel. The graph range extends 25% beyond both limits to account for any actions closing or opening on torque/thrust beyond the set limits.

**Dwell Log Graph**




Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized graph of that area.


### 5.7.3 CVA Torque Logs

The torque profile graphs show various traces of torque experienced by the actuator across a full stroke. The torque reference is a saved stroke trace that is configured during the auto-setup stage when commissioning the unit. These graphs will display thrust profiles for CVL actuators.

**Close Torque Profile**




**Open Torque Profiles**



Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized representation of that area. All traces can be selected/deselected to provide bespoke comparisons.

## 5.7.4 CVA Movement Log

The movement profile graph displays the actuator position and the demanded position of the CVA. This will include all controlling actions and any failsafe action under UPS power.



## **6.0 IQ3 Settings**

### **6.1 Actuator Information**

- 6.1.1 Actuator User Information
- 6.1.2 Actuator Serial Numbers
- 6.1.3 Actuator Manufacturing Information
- 6.1.4 Actuator Software Information

### **6.2 Actuator Name Plate**

- 6.2.1 Actuator Name Plate Info
- 6.2.2 Valve Manufacturing Information
- 6.2.3 Gearbox Manufacturing Information

### **6.3 Actuator Settings**

- 6.3.1 Basic Settings
- 6.3.2 ESD Configuration
- 6.3.3 Remote Configuration
- 6.3.4 Local Configuration
- 6.3.5 Special Mode Configuration

### **6.4 Torque Settings**

- 6.4.1 Current Torque Readings
- 6.4.2 Actuator Torque Settings
- 6.4.3 Torque Engineering Settings
- 6.4.4 Torque Advanced Settings
- 6.4.5 Torque Profile Settings

### **6.5 Power Settings**

- 6.5.1 Power Type
- 6.5.2 Battery Settings

### **6.6 Digital Input Settings**

- 6.6.1 DI Function
- 6.6.2 DI Input Type

### **6.7 Partial Stroke Settings**

- 6.7.1 Partial Stroke Enable
- 6.7.2 Partial Stroke Initial Position
- 6.7.3 Partial Stroke Position (%)
- 6.7.4 Partial Stroke Time to Position (sec)
- 6.7.5 Partial Stroke Time to Limit (sec)

### **6.8 Relay Settings**

- 6.8.1 Monitor Relay Function
- 6.8.2 Relay Settings

## **6.9 Option Control**

- 6.9.1 Option Source Selection
- 6.9.2 Auxiliary Mask Configuration
- 6.9.3 Option 1-4 Configuration

## **6.10 Control Settings**

- 6.10.1 Position Calibration
- 6.10.2 Position Settings
- 6.10.3 Movement Settings
- 6.10.4 Interrupter Timer

## **6.11 UI Settings**

- 6.11.1 Indication Configuration
- 6.11.2 Communication Configuration

## **6.12 Language Settings**

- 6.12.1 Display Language
- 6.12.2 Language Option Details

## **6.13 AMS Encoder**

- 6.13.1 Position Encoder Absolute Position
- 6.13.2 Position Encoder Status

## 6.1 Actuator Information

The Actuator Information comprises of technical information about the actuator that will help to identify spare parts and important test dates.

### Actuator Information

Actuator User Information	
Valve label	Main Isolating 2712
Actuator Serial Numbers	
Actuator	Z624431203
Main Controller	1226BX0160004503=107711
Position Sensor	1226BX0160023601=103311
Torque Sensor	2612503022006=101671
User Interface	1226BX0160001504=101131
Option 1	1227BX0160002901=103041
Option 2	
Option 3	
Option 4	
Power Board	1226BX0160004902=102391
DC Power Board (if fitted)	
Solid State Starter Board (if fitted)	
Actuator Manufacturing Information	
Date of Manufacture	20120829
Service Commission Date	
Service Inspection Date	
Factory Acceptance Test Date	
Wiring Diagram	123B0000

### 6.1.1 Actuator User Information

#### *Valve Label*

This is a user defined description of up to 32 Characters long. It is normally used to denote the function or location of the actuator or valve.

### 6.1.2 Actuator Serial Numbers

#### *Actuator*

Shows the serial number of the connected actuator.

#### *Main Controller*

For indication only, shows the serial number of the main controller board.

#### *Position Sensor*

For indication only, shows the serial number of the Position Sensor.

#### *Torque Sensor*

For indication only, shows the serial number of the Torque Sensor.

#### *User Interface*

For indication only, shows the serial number of the User Interface.

#### *Option 1*

For indication only, shows the serial number of Option card 1 (if fitted).

#### *Option 2*

For indication only, shows the serial number of Option card 2 (if fitted).

### ***Option 3***

For indication only, shows the serial number of Option card 3 (if fitted).

### ***Option 4***

For indication only, shows the serial number of Option card 4 (if fitted).

### ***DC Power board***

For indication only, shows the serial number of the DC power board (for DC only).

### ***Power Board***

For indication only, shows the serial number of the power board (for AC only).

### ***Solid State Starter board***

For indication only, shows the serial number for the Solid State Starter board (if fitted).

## **6.1.3 Actuator Manufacturing Information**

### ***Date of Manufacture***

For indication only, shows the manufacture date of the actuator.

### ***Service Commission Date***

Shows the date the actuator was commissioned by a Rotork Engineer.

### ***For indication only, shows Inspection Date***

For indication only, shows when the actuator is due its next inspection.

### ***Factory Acceptance Test Date***

For indication only, shows when the actuator was factory tested by Rotork.

### ***Wiring Diagram***

For indication only, shows the wiring diagram number for the actuator.

## 6.2 Actuator Name Plate

This menu replicates the physical name plate information visible on the actuator gear case. Should the nameplate become damaged, the correct information will still be retained in this section.

### Actuator Name Plate

Actuator Name Plate Info	
Actuator Rated Torque (lb ft)	60
Actuator Voltage	240
Actuator Frequency	50
Actuator Wiring Diagram	123B0000
Actuator Wiring Diagram Issue	-1
Actuator Size	IQS12
Actuator Speed	24
Actuator Base	F10
Actuator Coupling	A
Actuator Enclosure	ExdIIBT4
Actuator GearBox	N
Valve Manufacturing Information	
Valve Tag	PD1032
Valve Serial Number	D121205
Valve Type	Wedge Gate
Valve Size	6"
Valve Class	150
Valve Manufacturer	Crane
Valve Service Fluid	JetA1
Valve Service Temperature	20
Valve Location	Pump1032
Valve Installation Date	230913
Gearbox Manufacturing Information	
Gearbox Serial Number	GearSerial
Gearbox Mechanical Advantage	MechAdv
Gearbox Ratio	GearRati

### 6.2.1 Actuator Name Plate Info

#### *Actuator Rated Torque*

For indication only, shows the rated output torque of the actuator.

#### *Actuator Voltage*

For indication only, shows the supply voltage the actuator is configured to receive.

#### *Actuator Frequency*

For indication only, shows the actuator supply voltage frequency (Hz).

#### *Actuator Wiring Diagram*

For indication only, shows the actuator wiring diagram number which determines the specific internal wiring of the actuator.

#### *Actuator Wiring Diagram Issue*

For indication only, shows the issue number of the wiring diagram upon installation. This is important as the wiring diagram may have been superseded at a later date.

#### *Actuator Size*

For indication only, shows the actuator size and type. For example an IQS12 is a single phase IQ12.



### ***Actuator Speed***

For indication only, shows the speed of the actuator in revolutions per minute (RPM).

### ***Actuator Base***

For indication only, shows what size base flange is fitted to the actuator.

### ***Actuator Coupling***

For indication only, shows what size coupling the actuator is fitted with.

### ***Actuator Enclosure***

For indication only, shows what enclosure type the actuator has.

### ***Actuator Gearbox***

For indication only, shows what gearbox is attached to the actuator. If there is no gearbox is fitted to the actuator this will be listed as N.

## **6.2.2 Valve Manufacturing Information**

### ***Valve Tag***

This is similar to the actuator valve label (see section 6.1.1). A user defined label consisting of 16 alpha-numeric or symbolic characters. It is normally used to denote valve location or function.

### ***Valve Serial Number***

Input for the serial number of the attached valve. 10 alpha-numeric or symbolic characters are available to input the valve serial number.

### ***Valve Type***

Input for the type of the attached valve. 10 alpha-numeric or symbolic characters are available to input the valve type.

### ***Valve Size***

Input for the size of the attached valve. 10 alpha-numeric or symbolic characters are available to input the valve size.

### ***Valve Class***

Input for the valve classification. 10 alpha-numeric or symbolic characters are available to input the valve classification.

### ***Valve Manufacturer***

Input for detail of the valve manufacturer. 10 alpha-numeric or symbolic characters are available to input the valve classification.

### ***Valve Service Fluid***

Input for the fluid flowing through the valve. 10 alpha-numeric or symbolic characters are available to input the valve classification.

### ***Valve Service Temperature***

Input for the maximum operating temperature of the valve before requiring a service. 5 alpha-numeric or symbolic characters are available to input the valve classification.

### ***Valve Location***

Input for detail of the valve's location. 10 alpha-numeric or symbolic characters are available to input the valve location.

### ***Valve Installation Date***

Record for when the valve was installed. 8 alpha-numeric or symbolic characters are available to input the valve installation date.

## **6.2.3 Gearbox Manufacturing Information**

### ***Gearbox Serial Number***

Record for the serial number of the actuator gearbox. If no gearbox is fitted the default value will be blank or GearSerial.

### ***Gearbox Mechanical Advantage***

Record for the mechanical advantage of the gearbox. If no gearbox is fitted the default value will be blank or MechAdv.

### ***Gearbox Ratio***

Record for the internal gear ratio of the gearbox. If no gearbox is fitted the default value will be blank or GearRati.

## 6.3 Actuator Settings

This screen displays the current actuator settings. These settings are all relevant to standard actuator control functions.

### Actuator Settings

Basic Settings		
Close Action	<input type="radio"/> Position	<input checked="" type="radio"/> Torque
Open Action	<input checked="" type="radio"/> Position	<input type="radio"/> Torque
Direction to Close	<input checked="" type="radio"/> Clockwise	<input type="radio"/> Anti-Clockwise
ESD Configuration		
ESD Action	ESD Stop	
ESD Contact Type	<input type="radio"/> Normally Closed	<input checked="" type="radio"/> Normally Open
ESD Override Interlock	<input checked="" type="radio"/> No	<input type="radio"/> Yes
ESD Override Local Stop	<input checked="" type="radio"/> No	<input type="radio"/> Yes
ESD Override Thermostat	<input checked="" type="radio"/> No	<input type="radio"/> Yes
ESD Override Interrupter Timer	<input checked="" type="radio"/> No	<input type="radio"/> Yes
ESD Input Function	<input checked="" type="radio"/> ESD	<input type="radio"/> Network Control Disable
Remote Configuration		
Two Wire Priority	Stop Priority	
Interlock Mode	Disabled	
Fast Remotes (DC Only)	<input checked="" type="radio"/> Disabled	<input type="radio"/> Enabled
Push to Run Past Limit	<input checked="" type="radio"/> Disabled	<input type="radio"/> Enabled
Local Configuration		
Local Push to Run	<input checked="" type="radio"/> Disabled	<input type="radio"/> Enabled
Local Close Dominant Mode	<input checked="" type="radio"/> Disabled	<input type="radio"/> Enabled
Setting Tool Local Control	<input type="radio"/> Disabled	<input checked="" type="radio"/> Enabled
Vandal Resist Mode	Vandal Resist Off	
Local Control Special Modes	Special Modes Off	
Local Qualification Time (sec)	<input type="text" value="0.1"/>	
Local Controls Action on Network Comms Loss	After Comms loss action no change of mode	
Local Controls Selector Control	Local Controls Selector Disabled	
Aux1 indicates Local Controls Selector in Remote	Disabled	
Special Mode Configuration		
Special Mode Setup	Special Modes Disabled	
Velan Switch Compensation	<input type="text" value="0"/>	

### 6.3.1 Basic Settings

#### Close Action

The actuator can be configured to close on torque for seating valve types or limit for non-seating valve types. Limit means the actuator will stop moving once it reaches the set closed travel limit. Torque means the actuator will stop when it reaches the set closed torque limit (**Default 40% of Rated**).

#### Open Action

The actuator can be configured to open on torque for back-seating valve types or limit for non-back-seating valve types. Limit means the actuator will stop moving once it reaches the set open travel limit. Torque means the actuator will stop when it reaches the set open torque limit (**Default 40% of Rated**).

#### Direction to Close

This sets the direction of rotation for the actuator to perform a close operation to the valve. There are two available settings; clockwise and anti-clockwise. A close command will always operate in the set direction; therefore a reversal of controls is not required when changing the operating direction to suit the valve.

## 6.3.2 ESD Configuration

### *ESD Action*

This function sets the emergency shutdown action. There are four options.

**ESD CLOSE:** Upon receiving an ESD signal this setting will cause the actuator to close using the action set in the 'Close Action' screen. See section 6.3.1.

**ESD Stop:** Upon receiving an ESD signal this option will cause the actuator to stop.

**ESD Open:** Upon receiving an ESD signal this option will cause the actuator open using the action set in the 'Open Action' screen. See section 6.3.1.

**ESD OFF:** The ESD function has been disabled. Applying an ESD signal will not affect the actuator operation.

### *ESD Normally Closed*

This setting dictates if the ESD action will be performed when a signal is applied (normally open) or removed (normally closed).

### *ESD Override interlock*

This setting specifies if the ESD action should override an active interlock. **(Default Setting: No)**

### *ESD Override Local stop*

This setting specifies if the ESD action should override a local stop command. The local control selector has to be in the stop position to actively apply a local stop command. **(Default Setting: No)**

### *ESD Override Thermostat*

This setting specifies if the ESD action should override an active thermostat trip. **(Default Setting: No)**

### *ESD Override Interrupter Timer*

This setting specifies if the ESD action should override the interrupter timer function. **(Default Setting: No)**

### *ESD Input Function*

The function of the ESD input can be configured in two different ways.

**ESD:** When an ESD signal is received by the actuator it will perform its ESD action taking into account any override settings.

**Network Control Disable:** When an ESD signal is received by the actuator it will disable all network control inputs until the ESD signal is removed. During this period the actuator can only be controlled via hardwired remote inputs determined by the auxiliary mask setting.

### 6.3.3 Remote Configuration

#### *Two Wire Priority*

This sets the action the actuator will take when a close and open signal are applied simultaneously.

**Open Priority:** The actuator will run open if both signals are applied.

**Stop Priority:** The actuator will stay put or stop moving if both signals are applied.

**Close Priority:** The actuator will run closed if both signals are applied.

#### *Interlock Mode*

This sets the mode for the interlock inputs. Refer to the actuator wiring diagram for installation details. To operate the actuator when an interlock mode is enabled, an interlock signal must be applied in the appropriate direction whilst providing a control signal.

**Disabled:** The interlock inputs are disabled.

**Interlocks Enabled:** Interlocks are enabled for local and remote operation.

**Conditional Control Enabled:** Interlocks are enabled in remote control only.

**Partial Stroke On Open Interlock Enabled:** The open interlock will act as a remote input to initiate a partial stroke test.

#### *Fast Remotes (DC Only)*

For indication only, this setting reduces the minimum required control signal pulse length. **(Default Setting: Disabled)** Rotork Service Engineer use only.

#### *Push to run past limit*

This function will cause the actuator control signal to be Maintained once the actuator limit setting has been passed. **(Default: Enabled)**

### 6.3.4 Local Configuration

#### *Local Push to Run*

When enabled this changes the local open/close control knob function to a push to run operation. The knob position must be manually maintained for the actuator to run, upon removal of the signal the actuator will stop.

#### *Local Close Dominant Mode*

For indication only, this setting means that when a local close control command is applied it will override all other types of control. **(Default: Disabled)** Rotork Service Engineer use only.

#### *Setting Tool Local Control*

This setting enables the actuator to be controlled using the open, close and stop commands on the setting tool.

#### *Vandal Resist Mode*

The vandal resist mode is aimed at preventing unauthorised actuator operation. There are four options available.

**Vandal Resist Off:** All control knobs are active and the actuator will respond to all inputs, providing the unit is in the correct control mode. **(Default)**

**Vandal Resist Local:** In this mode the local and remote controls are disabled. The actuator can only be controlled by the open, close and stop commands on the setting tool.

**Vandal Resist Remote:** In this mode all local controls, including the setting tool, are disabled. The actuator can only be controlled by remote inputs.

**Vandal Resist Local/Remote Switch:** Ignore this option as it is currently not a valid setting in the IQ software.

### *Local Control Special Modes*

There are various special local control modes that can be configured for the IQ3 actuator. Rotork Service Engineer use only.

**External Local\Remote Switch:** An external local/remote switch will be used to switch modes instead of the local control knob.

**Allow Remote Commands In Local:** This allows remote controls to operate the actuator whilst it is in local control mode.

**Allow Remote Commands In Local Plus External Local\Remote Switch:** Remote control commands can operate the actuator whilst it is in local control mode. To switch between local and remote modes an external local/remote switch will be used instead of the local control knob selector.

Remote selection of Remote/Local via Relays DO5 and DO6 write.

### *Local Qualification time (sec)*

This is where the local qualification time in seconds can be viewed and set. The local qualification time of the actuator is how long a local control signal must be present before the actuator will accept that signal and respond accordingly. Rotork Service Engineer use only.

### *Local Controls Action on Network Comms Loss*

This setting specifies the reaction of the actuator during a network communications loss condition. Rotork Service Engineer use only.

### *Local Controls Selector Control*

This setting specifies the local control selector controlling element. Rotork Service Engineer use only.

### *Aux1 Indicates Local Controls Selector in Remote*

This setting reassigns Aux1 as remote indication of the local controls selector state. Rotork Service Engineer use only.

## **6.3.5 Special Mode Configuration**

### *Special Mode Setup*

Refer to the full IQ3 configuration manual for more information on special operating modes. Rotork Service Engineer use only. The special modes available are:

**Special Modes Disabled:** This setting is for standard operation and feedback. **(Default)**

**Fetterolf Mode Enabled:** This enables the Fetterolf operating mode.

**Velan Mode Enabled:** This enables the Velan operating mode.

**Velan Mode with Reset Enabled:** This enables the Velan operating mode with the reset function available (must be used in conjunction with the optional Digital Input / Output card).

### *Velan Switch Compensation*

Adjust the Velan switch compensation function when Velan reset is enabled. Rotork Service Engineer use only.

## 6.4 Torque Settings

This section shows all the information and settings relevant to actuator torque.

### Torque Settings

Current Torque Readings	
Current Torque Value (%)	82
Actuator Torque Settings	
Close Torque Percentage	<input type="range" value="100"/> 100
Open Torque Percentage	<input type="range" value="40"/> 40
Torque Advanced Settings	
Torque Boost Open Direction	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled
Torque Boost Close Direction	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled
Boost Level	<input checked="" type="radio"/> 150% Rated Torque <input type="radio"/> Stall Torque
Torque Boost Open Position (%)	<input type="range" value="5"/> 5
Torque Boost Close Position (%)	<input type="range" value="95"/> 95
Torque Profile Settings	
Torque Profile Open	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled
Torque Profile Close	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled

### 6.4.1 Current Torque Readings

#### Current Torque Value (%)

For indication only, shows the current torque value as a percentage of rated torque.

### 6.4.2 Actuator Torque Settings

#### Torque percent close

The percentage of rated torque permitted to close the valve. This is configurable between 40% - 100%.  
**(Default = 40%)**

#### Torque percent open

The percentage of rated torque permitted to open the valve. This is configurable between 40% -100%.  
**(Default = 40%)**

### 6.4.3 Torque Advanced Settings

#### Torque Boost Open Direction

Gives the option to enable or disable the torque boost function in the open direction.

#### Torque Boost Close Direction

Gives the option to enable or disable the torque boost function in the closed direction.

#### Boost Level

This enables the user to choose the percentage of rated torque the actuator will output when performing a boost function. The options are:

**150% Rated Torque:** This allows the actuator to output 150% of rated torque. **(Default)**

**Stall Torque:** This allows the actuator to apply between 140% and 200% of rated torque.

#### Torque Boost Open Position (%)

This option allows the user to set the position from which the torque boost will activate in the open direction. This is shown as a percentage of total travel. **(Default: 5%)**

#### Torque Boost Close Position (%)

This option allows the user to set the position from which torque boost will activate in the close direction. This is shown as a percentage of total travel. **(Default: 5%)**

## 6.4.4 Torque Profile Settings

### *Torque Profile Open*

Allows the plotting of the torque profile in the open direction to be enabled or disabled.

### *Torque Profile Close*

Allows the plotting of the torque profile in the close direction to be enabled or disabled.

## 6.5 Power Settings

This menu displays power settings relating to the actuator type and battery.

### Power Settings

Power Type	
Power Supply Type	Single-Phase
Solid State Starter Brake	Brake Off
Modulating Actuator	<input checked="" type="radio"/> Isolating <input type="radio"/> Modulating

### 6.5.1 Power Type

#### *Power Type*

For indication only, shows the power type of the actuator. The power type options are:

**Three Phase Standard:** For three phase supply actuators which are not built to modulating specification.

**Single Phase:** For single phase supply actuators.

**DC:** For direct current supply actuators.

**Three Phase Modulating:** For three phase supply actuators which are built to a modulating specification.

#### *Solid State Starter Brake*

The Solid State Starter brake injects a DC voltage into the motor in order to slow the magnetising of the fields and bring the motor to a halt. In this setting, the option for the Solid State Starter brake is viewed and set, **only available for actuators with a Solid State Starter fitted**. The options available are;

**Brake Off:** The Solid State Starter brake is off.

**Brake Open:** The brake is active in the open direction only.

**Brake Close:** The brake is active in the close direction only.

**Brake Open and Close:** The brake is active in both the open and close direction.

#### *Modulating Actuator*

For indication only, shows whether the actuator is built for Isolating or Modulating duty.



## 6.6 Digital Input Settings

The following settings are applicable to Digital Inputs 7-14.

### Digital Input Settings

Digital Input 7	
DI 7 Function	Disabled
DI7 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 8	
DI 8 Function	Disabled
DI8 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 9	
DI 9 Function	Disabled
DI9 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 10	
DI 10 Function	Disabled
DI10 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 11	
DI 11 Function	Disabled
DI11 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 12	
DI 12 Function	Disabled
DI12 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 13	
DI 13 Function	Disabled
DI13 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 14	
DI 14 Function	Disabled
DI14 Input Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed

### 6.6.1 DI Function

This is where the function of a digital input can be viewed and set. The available options are:

**Disabled:** The selected digital input is disabled.

**Remote Open:** The digital input will trigger a remote open signal.

**Remote Close:** The digital input will trigger a remote close signal.

**Remote Maintain:** The digital input will trigger a remote maintain signal.

**Remote ESD:** The digital input will trigger a remote ESD signal.

**Open Interlock:** The digital input will trigger an open interlock signal (local and remote).

**Close Interlock:** The digital input will trigger a close interlock signal (local and remote).

**Network Disable:** The digital input will disable network control.

**Partial Stroke:** The digital input will trigger a partial stroke test.

**Hand / Auto:** The digital input will switch between hand and auto mode (H/W control and Analogue control)

**Velan Reset:** The digital input will perform a Velan reset.

**Conditional Open:** The digital input will trigger an open interlock signal (remote only)

**Conditional Close:** The digital input will trigger an Close interlock signal (remote only)

**Local / Remote Switch:** The digital input will toggle between Local/ Remote producing the relevant signals.

### 6.6.2 DI Input Type

Here the digital input can be configured to Normally Open or Normally Closed contact type.

## 6.7 Partial Stroke Settings

### Partial Stroke Settings

Partial Stroke	
Partial Stroke Enable	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled
Partial Stroke Initial Position	<input checked="" type="radio"/> Open Limit <input type="radio"/> Closed Limit
Partial Stroke Position (%)	<input type="range" value="95"/> 95
Partial Stroke Time to Position (sec)	<input type="range" value="60"/> 60
Partial Stroke Time to Limit (sec)	<input type="range" value="60"/> 60

### 6.7.1 Partial Stroke Enable

This specifies whether partial stroke is enabled or disabled.

### 6.7.2 Partial Stroke Initial Position

The position that the actuator must be in before it will perform a partial stroke test. This can be set to either the open or closed limit.

### 6.7.3 Partial Stroke Position (%)

The position the actuator will run to during the partial stroke test.

### 6.7.4 Partial Stroke Time to Position (sec)

The maximum allowable time the actuator can take to run from the initial position to the partial stroke position. If the actuator fails to perform this part of the partial stroke test in the specified time an alarm will trigger for partial stroke test failure.

### 6.7.5 Partial Stroke Time to Limit (sec)

The maximum allowable time the actuator can take to run from the partial stroke position back to its initial position. If the actuator fails to perform this part of the partial stroke test in the specified time and alarm will trigger for partial stroke test failure.

## 6.8 Relay Settings

**Relay Settings**

<b>Monitor Relay</b>	
Monitor Relay Function	Available
<b>Relay S1 Settings</b>	
Relay S1 Function	Intermediate Position
Relay S1 Control Value (%)	<input type="range"/> 21
Relay S1 Contact Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
<b>Relay S2 Settings</b>	
Relay S2 function	Open Limit
Relay S2 control value (%)	<input type="range"/> 0
Relay S2 Contact Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
<b>Relay S3 Settings</b>	
Relay S3 Function	Phase Loss
Relay S3 Control Value (%)	<input type="range"/> 0
Relay S3 Contact Type	<input type="radio"/> Normally Open <input checked="" type="radio"/> Normally Closed
<b>Relay S4 Settings</b>	
Relay S4 Function	None
Relay S4 Control Value (%)	<input type="range"/> 0
Relay S4 Contact Type	<input type="radio"/> Normally Open <input checked="" type="radio"/> Normally Closed
<b>Relay S5 Settings</b>	
Relay S5 Function	Phase Loss
Relay S5 Control Value (%)	<input type="range"/> 0
Relay S5 Contact Type	<input type="radio"/> Normally Open <input checked="" type="radio"/> Normally Closed
<b>Relay S6 Settings</b>	
Relay S6 function	None
Relay S6 control value (%)	<input type="range"/> 0
Relay S6 contact type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
<b>Relay S7 Settings</b>	
Relay S7 function	None
Relay S7 Control Value (%)	<input type="range"/> 0
Relay S7 Contact Type	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
<b>Relay S8 Settings</b>	
Relay S8 Function	None

### 6.8.1 Monitor Relay Function

Denotes the function of the monitor relay. This can be set to either Available or Fault. In Available mode the relay is active when the actuator is ready and available for remote control. In fault mode the relay will be active when the actuator has an active fault condition and will ignore the status of the local / remote selector.

## 6.8.2 Relay Settings

The following settings are applicable to Relays S1-S12

### Relay Function

IQ3 Function	Insight 2 Function
Disabled	None
Closed Limit	Closed Limit
Open Limit	Open Limit
End Position	End Position
Pos % open	Intermediate Position
Mid Travel	Actuator Mid Travel
Motor Running	Motor Running
Closing	Closing
Opening	Opening
Moving	Moving
Handwheel	Manual Override Switch
Blinker	Blinker
Valve Alarm	Valve Alarm
Torque Trip CL	Torque Trip Close
Torque Trip OP	Torque Trip Open
Torque Trip	Torque Trip
Torque Trip Mid	Torque Trip Mid-Travel
Motor Stall	Stall (any Position)
Mid Travel Stall	Stall (Mid-Travel)
Stop Selected	Stop Selected
Local Selected	Local Selected
Remote Selected	Remote Selected
Control Alarm	Control Alarm
Monitor	Monitor Output
ESD Active	ESD Active

IQ3 Function	Insight 2
Open Interlock Active	Open Interlock
Close Interlock Active	Close Interlock
Interlock Active	Interlock
Actuator Alarm	Actuator Alarm
Lost Phase	Phase Loss
24v Supply Fail	Customer 24V Fail
P Stroke Active	Partial Stroke Active
P Stroke Fail	Partial Stroke Fail
P Stroke Pass	Partial Stroke Pass
Bluetooth	<i>Bluetooth</i> Connected
Battery Low	Battery Low
Battery Discharged	Battery Flat
Digital Output	S1-12 Digital Output (Number depends on relay number)
Maintenance	Maintenance Required
Hi Torque Alarm	Hi Torque Alarm Active
Hi Hi Torque Alarm	Hi Hi Torque Alarm Active
Option Source 1 Comms Loss	Option Source 1 Comms Loss
Option Source 2 Comms Loss	Option Source 2 Comms Loss
Namur Maintenance Level	Namur Maintenance Level
Namur Out of Specification level	Namur Out of Specification level
Namur Function Check Level	Namur Function Check Level
Namur Failure level	Namur Failure level

For descriptions of the various relay function please refer to the IQ3 Full Configuration Manual

### Relay Control Value (%)

This is used for relevant positional relay functions and is configurable from 0% to 100% in increments of 0.1%.

### Relay Contact Type

This allows the relays contact type to be configured for normally open or normally closed operation.

## 6.9 Option Control

### Option Control

Option Source Selection	
Source 1 Control Type	Analogue
Source 2 Control Type	None
Remote Source Selection	Hardwired Switched Source 1 Control
Auxiliary Mask Configuration	
Digital Input 1 Type	<input checked="" type="radio"/> Digital Input <input type="radio"/> Remote Open
Digital Input 1 Active State	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 2 Type	<input checked="" type="radio"/> Digital Input <input type="radio"/> Remote Close
Digital Input 2 Active State	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 3 Type	<input checked="" type="radio"/> Digital Input <input type="radio"/> Remote Maintain
Digital Input 3 Active State	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Digital Input 4 Type	<input type="radio"/> Digital Input <input checked="" type="radio"/> Remote ESD
Digital Input 4 Active State	<input checked="" type="radio"/> Normally Open <input type="radio"/> Normally Closed
Option 1 Configuration	
Option 1 Type	Analogue
Option 1 Communications Loss Action	Stop Action
Option 1 Communications Loss Time	<input type="text" value="0"/>
Comms Loss Timeout Scale	Milliseconds
Option 1 Communications Loss Position (%)	<input type="text" value="0"/>
Option 2 Configuration	
Option 2 Type	Extra Relay S5-S8 Board
Option 2 Communications Loss Action	Stop Action
Option 2 Communications Loss Time	<input type="text" value="0"/>
Comms Loss Timeout Scale	Milliseconds
Option 2 Communications Loss Position (%)	<input type="text" value="0"/>
Option 3 Configuration	
Option 3 Type	None
Option 3 Communications Loss Action	Off
Option 3 Communications Loss Time	<input type="text" value="10000"/>
Comms Loss Timeout Scale	Milliseconds
Option 3 Communications Loss Position (%)	<input type="text" value="50"/>

### 6.9.1 Option Source Selection

#### Source 1 Control Type

Configure the source 1 control type from a list of fitted control options.

#### Source 2 Control Type

Configure the source 2 control type from a list of fitted control options.

#### Remote Source Selection

This is where the source for remote control is selected. The options for source selection are:

**Hardwired Control:** The actuator can be controlled by hardwired remote controls.

**Source 1 Option Control:** The actuator is controlled by the network selected in Source 1.

**Hardwired Switched Source 1 Control:** The actuator can be controlled by either hardwired remote controls or Source 1. A remote switch must be used to change between control sources.

**Source 1 Switched Source 2 Control:** The actuator can be controlled by either network selected in source 1 and source 2. A remote switch must be used to change between control sources.

**Remote Control Disabled:** The actuator will not respond to remote controls.

## 6.9.2 Auxiliary Mask Configuration

### *Digital Input 1 Type*

Configure Digital Input 1 to either Digital Input or Remote Open.

### *Digital Input 1 Active State*

The user can configure Digital Input 1 to a normally open or normally closed digital contact.

### *Digital Input 2 Type*

Configure Digital Input2 to either Digital Input or Remote Close.

### *Digital Input 2 Active State*

The user can configure Digital Input 2 to a normally open or normally closed digital contact.

### *Digital Input 3 Type*

Configure Digital Input 3 to either Digital Input or Remote Maintain.

### *Digital Input 3 Active State*

The user can configure Digital Input 3 to a normally open or normally closed digital contact.

### *Digital Input 4 Type*

Configure Digital Input 4 to either Digital Input or Remote ESD.

### *Digital Input 4 Active State*

The user can configure Digital Input 4 to a normally open or normally closed digital contact.

## 6.9.3 Option 1-4 Configuration

### *Option Type*

This is where option card slots 1 – 4 can be configured to recognise the following option cards:

Profibus

Pakscan

Modbus

Folomatic

Foundation Fieldbus

Hart

None

Extra Relay board

Digital IO Board

Folomatic Board Two

Foundation Fieldbus Board Two

Modbus Board Two

Pakscan Board Two

Extra Relay Board Two

Profibus Board Two

Digital IO Board Two

Hart Board 2

### Option Communication Loss Action

Configure how the actuator will respond to a loss of option communication. The available actions are:

**Off:** The communication loss action is turned off.

**Open Action:** The actuator will run to the open limit.

**Close Action:** The actuator will run to the closed limit.

**Stop Action:** The actuator will stop.

**Go To Position Action:** The actuator will run to a predetermined position.

### Option Communication Loss Time

The user can specify the amount of time before a loss of communications is recognised as an alarm. This is configurable between 0 and 65.

### Coms Loss Timeout Scale

The units for Option Communication Loss Time can be adjusted from Milliseconds to Seconds to suit the specific application.

### Option Communications Loss Position (%)

Upon loss of communication to the option card, the actuator will move to this position. This is only applicable if the actuator is configured to Go To Position on loss of communications. Position is shown as a percentage of total travel.

## 6.10 Control Settings

### Control Settings

Set Limits	
Set Open Limit	<a href="#">Click Here to Set Open Limit</a>
Set Closed Limit	<a href="#">Click Here to Set Closed Limit</a>
Position Settings	
Min Span Position (%)	<input type="range" value="0"/> 0
Max Span Position (%)	<input type="range" value="100"/> 100
Deadband (%)	<input type="range" value="5"/> 5
Hysteresis Band (%)	<input type="range" value="2"/> 2
Motion Inhibit Time (sec)	<input type="range" value="2"/> 2
Interrupter Timer	
Interrupter Timer Enable	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
Interrupter Timer Close Position (%)	<input type="range" value="20"/> 20
Interrupter Timer Open Position (%)	<input type="range" value="50"/> 50
Interrupter Timer On Time (sec)	<input type="range" value="2"/> 2
Interrupter Timer Off Time (sec)	<input type="range" value="2"/> 2

### 6.10.1 Set Limits

#### Set Open Limit

This sets the open limit at the current position of the actuator.

#### Set Closed Limit

This sets the closed limit at the current position of the actuator.

## 6.10.2 Position Settings

### ***Min Span Position (%)***

This setting can restrict the minimum allowable travel position without adjusting the set limits.

### ***Max Span Position (%)***

This setting can restrict the maximum allowable travel position without adjusting the set limits.

### ***Deadband (%)***

Shows the Deadband setting for the actuator. Refer to the IQ3 Full Configuration Manual for Details.

### ***Hysteresis Band (%)***

Shows the Hysteresis Band setting for the actuator. Refer to the IQ3 Full Configuration Manual for Details.

### ***Motion Inhibit Time (Sec)***

This is the amount of time the actuator will not respond to a control signal after moving to a new position. This is configurable from 0 – 1000 seconds.

## 6.10.3 Interrupter Timer

### ***Interrupter Timer Enable***

For indication only, shows whether the interrupter timer is enabled or disabled.

### ***Interrupter Timer Close Position (%)***

This is the position the interrupter timer will activate when running in the closed direction. Setting this to 0% will result in non-interrupted travel.

### ***Interrupter Timer Open Position (%)***

This is the position the interrupter timer will activate when running in the open direction. Setting this to 100% will result in non-interrupted travel.

### ***Interrupter Timer On Time (sec)***

The time the interrupter timer will be active for before turning off. This is the pause length while the interrupter timer acting on a movement.

### ***Interrupter Timer Off Time (sec)***

The time the interrupter timer will be inactive for before turning on. This is the period of movement between each interruption.



## 6.11 UI Settings

### UI Settings

Indication Configuration	
Home Screen	Position
Mid-Travel LED Function	Enabled
Alarm LED Setting	Disabled
Close Limit LED Colour	<input checked="" type="radio"/> Green <input type="radio"/> Red
LED Luminosity Level (%)	<input type="range"/> 100
Display Language	English
BackLight Timeout On Mains (0 = Always ON) (sec)	<input type="range"/> 0
Communication Configuration	
Bluetooth Enabled	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled
Bluetooth Security Level	Low - Discover Always

### 6.11.1 Indication Configuration

#### Home Screen

There are four different home screen options:

**Position:** This shows the position of the actuator as a percentage.

**Torque Analogue Plus Position:** This shows the position of the actuator and an analogue torque meter.

**Torque Digital Plus Position:** This shows the position of the actuator and a digital torque readout in Nm.

**Positioner:** This shows a digital and analogue readout of position and demand. Demand will only be shown when the actuator is controlled by a network or a 4-20mA signal.

#### Mid Travel LED Function

Shows the current function of the Mid Travel LED, the functions available are:

**Disabled:** The LED will be off.

**Enabled:** The LED will be active when the actuator is not at its limits.

**Blinker:** The yellow lights will blink when the actuator is travelling and will remain on when the actuator is stopped.

**LED Blinks When Alarm present:** The yellow lights are on during mid-travel and will blink alternately when an alarm is present.

**LED ON when Alarm present:** The yellow lights will only come on blinking alternately when an alarm is present.

#### Alarm LED Setting

Shows the current setting for the Alarm LED.

**No Alarms Indicated:** The yellow lights will not indicate an active alarm.

**Active on any Alarm:** The LED will be active when an actuator or valve alarm is present if the appropriate option is set above.

**Active on any Service alarm:** The LED will be active when a Service alarm is present if the appropriate option is set. A service alarm indicates the actuator requires service, due to set duty parameters being met.

**Active on any Service or Alarm:** The yellow lights indicate active alarms and active service alarms if the appropriate option is set above. A service alarm indicates the actuator requires service due to set duty parameters being met.

#### Close Limit LED Colour

The colour of the close limit LED can be set, either red or green. The open limit LED will be the inverse of the close limit setting.

### LED Luminosity Level (%)

Shows the LED luminosity as a percentage of maximum luminosity.

### Display Language

Shows the language currently used on the display. This is linked to Display Language Section 6.12.1.

### Backlight Timeout on Mains (0 = Always ON) (sec)

Specify a period of time before the backlight is turned off whilst on mains power supply.

## 6.11.2 Communication Configuration


### Bluetooth Enabled

Specify whether the actuator *Bluetooth* is enabled or disabled. **Do not disable the internal Bluetooth without prior authority from Rotork.**

### Bluetooth Access Mode

The available options are:

**Very High Security – Infra Red Only:** All *Bluetooth* communication is disabled. Communication is by infrared commands from the Setting Tool only.

**High Security – Infra Red Initiation Only:** The actuator is not available for *Bluetooth* communication using a PC running Insight 2. Communication with the *Bluetooth* Setting Tool is available by holding the  key to initiate the *Bluetooth* connection using the Infrared initiation.

**Discover in Local and Stop:** The actuator is available for *Bluetooth* communication when it is in local or stop using the red selector. Connection is unavailable in Remote. The Local/Stop/Remote selector can be padlocked in all three positions. Communication with the *Bluetooth* Setting Tool is available.

**Discover Always:** The actuator is available for *Bluetooth* communication at all times using the Insight 2 PC software. This setting provides convenient connection when Insight 2 is used. Communication with the *Bluetooth* Setting Tool is available.

## 6.12 Language Settings

### Language Settings

<b>Language Configuration</b> ^	
Display Language	English ▼
<b>Language Option 1 details</b> ^	
Language	French
<b>Language Option 2 details</b> ^	
Language	Spanish
<b>Language Option 3 details</b> ^	
Language	German
<b>Language Option 4 details</b> ^	
Language	LastID 0
<b>Language Option 5 details</b> ^	
Language	LastID 0
<b>Language Option 6 details</b> ^	
Language	LastID 0
<b>Language Option 7 details</b> ^	
Language	LastID 0
<b>Language Option 8 details</b> ^	
Language	LastID 0

### 6.12.1 Display Language

Shows the language currently used on the display. This is linked to Display Language Section 6.11.1

## 6.12.2 Language Option Details

### Language

For indication only, shows the current language installed in the relevant language slot. Blank slots will be indicated with Last ID = 0.

## 6.13 Namur Settings

### Namur Settings

Namur Status		
Namur Maintenance Status Flag	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Namur Out of Specification Status Flag	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Namur Function Check Status Flag	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Namur Failure Status Flag	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Namur Maintenance Group Mask Settings		
Battery Low alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Local Fault alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Power fault alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Thermostat Tripped fault alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Contactor Service Limit	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Service Date Reached	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Torque HI HI Limit	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Torque HI Limit	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Valve fault Indication	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Turns Limit Exceeded	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Unavailable for Remote Control	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
ESD Inhibiting Control	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Actuator Control Inhibited	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Remote Communications Lost	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Hardware Error	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Partial Stroke Test Error	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Motor Starts Limit Reached	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Actuator Stalled	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Actuator Encoder in Limited Operation mode	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
End of Travel Timeout Exceeded	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Control Network Fault	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Customer 24V Supply Fault	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Valve Travel Timeout	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Operation Direction Fault	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Namur Out of Specification Group Mask Settings		
Battery Low alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Local Fault alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Power fault alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active
Thermostat Tripped fault alarm	<input checked="" type="radio"/> Inactive	<input type="radio"/> Active

### 6.13.1 Namur Status

#### *Namur Maintenance Status Flag*

Specify whether the Namur Maintenance alarm will trigger an actuator status should a configured condition become active.

#### *Namur Out of Specification Status Flag*

Specify whether the Namur Out of Specification alarm will trigger an actuator status should a configured condition become active.

#### *Namur Function Check Status Flag*

Specify whether the Namur Function Check alarm will trigger an actuator status should a configured condition become active.

### Namur Failure Status Flag

Specify whether the Namur Failure alarm will trigger an actuator status should a configured condition become active.

### 6.13.2 Namur Mask Settings (All groups)

This specifies the conditions that will trigger the Namur category alarm. Refer to PUB002-040 for further details on Namur settings for IQ3.

## 6.14 Analogue Control/CPT/CTT/AIO Option

### Analogue Control/CPT/CTT/AIO Option

<b>Analogue Card Type</b> ^	
Analogue Option Card Type	Folomatic/CPT build ▾
<b>Analogue Card Configuration</b> ^	
Analogue signal type	0-20mA ▾
Analogue Input signal inversion	Not inverted ▾
Analogue Output signal inversion	Not inverted ▾
Digital input (Hand/Auto)	<input type="radio"/> Enabled <input checked="" type="radio"/> Disabled
<b>Analogue Signal Calibration</b>	
<b>Software Version</b> ^	
Software Version	v105 ( 843)
<b>Status</b> ^	
Eeprom Status	<input type="radio"/> Error/Not Initialised <input checked="" type="radio"/> Okay
Analogue Input Status	<input checked="" type="radio"/> Okay - In range <input type="radio"/> Error - Out of range
CAN Comms Status	<input checked="" type="radio"/> Communications Good <input type="radio"/> Communications Failed
Analogue Input Status	<input checked="" type="radio"/> Input within range <input type="radio"/> Input out of range HIGH
Analogue Input Status	<input checked="" type="radio"/> Input within range <input type="radio"/> Input out of range LOW
Digital Input State	<input checked="" type="radio"/> Input Low (Auto) <input type="radio"/> Input High (Hand)

## 6.15 Extra Relays S5-S8

### Extra Relays S5-S8

<b>Extra Relays S5-S8 Status</b> ^	
Extra Relays S5-S8 Interface Type	26 ▾
Extra Relays S5-S8 Software Version	v102 ( 1919)

## **7.0 IQ3 Data Logger**

All the main IQ3 data logger functions have an adjustable scale that is proportional to the size of the Insight 2 window. Adjustment of graphical data, for increased or decreased detail, can be performed by expanding or contracting the program window.

### **7.1 Event Logger**

- 7.1.1 Time Line
- 7.1.2 Trace View
- 7.1.3 List View

### **7.2 Torque Profile**

### **7.3 Torque Limit Profiles**

### **7.4 Torque Reference Profile**

### **7.5 Torque Reference Limit Profiles**

### **7.6 Starts Log**

### **7.7 Movement Log**

### **7.8 Current Partial Stroke Profile**

### **7.9 Vibration Trend Log**

### **7.10 Battery Voltage and Temperature Trend Log**

- 7.10.1 Battery voltage Trend
- 7.10.2 Temperature Trend

### **7.11 Motor Starts and Output Turns Trend Log**

- 7.11.1 Output Turns Trend
- 7.11.2 Starts Trend

### **7.12 Miscellaneous Datalog Data**

- 7.12.1 Motor Related Data
- 7.12.2 Power Related Data
- 7.12.3 Limit Related Data
- 7.12.4 Environmental Related Data


## 7.1 Event logger

The Event Logger will store information related to actuator actions and condition changes. All events are date and time stamped to accurately assess the actuator operations.



The top scroll bar can be used to navigate from the first recorded event (far left) to the most recent event (far right). The recorded event number is shown with the event date and time stamp above the navigation bar.


### 7.1.1 Time Line



The Time Line display style provides the user with a visual indication of active conditions for the specific event selected with the top scroll bar. An active condition is indicated by a checked box. The dropdown menu is included to apply a filter. The Prev and Next actions buttons chronologically skip to the next recorded event for the chosen condition.


## 7.1.2 Trace View

The trace view provides a comparison between various event triggers during each period between events. The Position (%), Demand (%) and Torque (%) traces are analogue recorded values whilst other event conditions can be configured as Digital Traces.




The top scroll bar can be used to navigate through various events. There is also an additional scroll bar within the Trace view window. This can be used to adjust the scaling of both traces for more detailed analysis.

Each digital trace can be allocated a different function by opening the associated drop down menu and selecting the required condition.



### 7.1.3 List View

This type of display depicts the data event Log of the IQ3 in tabular format as a chronological series of events.




Time	Event	Position (%)	Demand (%)	Torque (%)
28/05/2014 10:41:15.534	Relay S3 State	18.22	0	0
28/05/2014 10:41:15.534	Relay S4 State	18.22	0	0
28/05/2014 10:41:15.784	Moving Open	26.38	0	0
28/05/2014 10:41:15.784	Primary Open	26.38	0	0
28/05/2014 10:41:15.784	Manual Movement	26.38	0	0
28/05/2014 10:41:15.784	Phase Rotation	26.38	0	0
28/05/2014 10:41:15.784	Relay S3 State	26.38	0	0
28/05/2014 10:41:15.784	Relay S4 State	26.38	0	0
28/05/2014 10:41:17.034	Primary Open	43.12	0	0
28/05/2014 10:41:17.034	Phase Rotation	43.12	0	0
28/05/2014 10:41:17.034	Relay S3 State	43.12	0	0
28/05/2014 10:41:17.034	Relay S4 State	43.12	0	0
28/05/2014 10:41:17.284	Moving Open	48.29	0	0
28/05/2014 10:41:17.284	Primary Open	48.29	0	0
28/05/2014 10:41:17.284	Manual Movement	48.29	0	0
28/05/2014 10:41:17.284	Phase Rotation	48.29	0	0
28/05/2014 10:41:17.284	Relay S3 State	48.29	0	0
28/05/2014 10:41:17.284	Relay S4 State	48.29	0	0
28/05/2014 10:41:18.534	Primary Open	52.9	0	0
28/05/2014 10:41:18.534	Phase Rotation	52.9	0	0
28/05/2014 10:41:18.534	Relay S3 State	52.9	0	0
28/05/2014 10:41:18.534	Relay S4 State	52.9	0	0

The top slider bar can be used to navigate through all available events currently in the data log. Alternatively the scroll bar on the right side of the event information can be used to navigate events in the same fashion.




## 7.2 Torque Profile



The torque profile graphs show graphical traces detailing the last recorded and average opening or closing torque as a percentage of rated torque by the actuator across a full stroke. This graphical display can be used to identify excessive valve wear.

Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized representation of that area. All traces can be selected/deselected to provide bespoke comparisons.


## 7.3 Torque Limit Profiles



Torque limit profile graphs show the measured torque in both directions around each position limit. The average torque is provided as a reference against the last recorded torque. This will help to identify any valve degradation at the fully closed or fully open positions.

Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized representation of that area. All traces can be selected/deselected to provide bespoke comparisons.


## 7.4 Torque Reference Profile



This screen displays the reference stroke for the actuator. The reference data is collected by stroking the valve during commissioning and saving the valve torque within the actuator settings.

Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized graph of that area.


## 7.5 Torque Reference Limit Profiles



This screen provides greater detail of the reference torque at each position limit. The reference data is collected by stroking the valve during commissioning and saving the valve torque within the actuator settings.

Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized representation of that area. All traces can be selected/deselected to provide bespoke comparisons.


## 7.6 Starts Log



This screen displays the total number of movements initiated in each direction against a position of full valve stroke.

Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized graph of that area.


## 7.7 Movement Log



The movement log records the actuator position, demand and torque as a percentage of rated across the data log period.

Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized graph of that area.


## 7.8 Current Partial Stroke Profile



This screen displays a torque graph of the last partial stroke movement for both directions. The torque required to operate the valve during the last partial stroke operation may help to diagnose problems with the valve and its condition.

Graph detail can be enhanced by dragging a selection area over a section of the graph. This will adjust the axis to zoom into a full sized graph of that area.


## 7.9 Vibration Trend Log



The vibration trend log screen displays the peak and average vibration detected by the actuator. The sensor is located on the circuit board and records vibration (G) in three axes. Peak values shown will be the highest recorded for that period. Vibration analysis graphs may help the user understand how plant induced vibration affects actuator/valve operation.


## 7.10 Battery Voltage and Temperature Trend Log

### 7.10.1 Battery Voltage Trend



Battery voltage is constantly monitored to ensure that actuator position and status can still be viewed during a power loss. The trend graph will identify a replacement battery is required if the measured voltage drops significantly.

### 7.10.2 Temperature Trend




The actuator ambient temperature is monitored to identify if the internal electronics are being exposed to an excessively high operating temperature. Operators can use this trend to issue a protective action should heat rise be witnessed (e.g. fitment of a sun shade in a hot outside unclouded environment).



## 7.11 Motor Starts and Output Turns Trend Log

### Motor Starts and Output turns Trend Log



The Output Turns trend provides a quick visual indication of actuator activity over a number of days. The Starts trend can be used in conjunction with the Output Turns trend to identify if the actuator is moving in an isolating fashion (large movements) or modulating fashion (small step changes).

## 7.12 Miscellaneous Datalog Data

### Miscellaneous Datalog Data

Motor Related Data	
Total Number Open Contactor Operations	201
Total Number Close Contactor Operations	196
Total Number Output Turns	13985
Maximum Number of Starts per Hour	25
Total Motor Run Time in 1/4 seconds	2934
Power Related Data	
Number of Power Cycles	229
Total Battery Run Time in 1/4 seconds	1738
Maximum Powered On Time in 1/4 seconds	635458
Maximum Powered Down Time in 1/4 seconds	1223702
Limit Related Data	
Maximum Open Limit Torque recorded	3
Maximum Close Limit Torque recorded	138
Average Torque recorded	84
Environmental Related Data	
Maximum recorded temperature	32
Minimum recorded temperature	0

### 7.12.1 Motor Related Data

#### ***Total Number Open Contactor Operations***

A decimal count of the number of experienced contactor operations in the Open direction.

#### ***Total Number Close Contactor Operations***

A decimal count of the number of experienced contactor operations in the Close direction.

#### ***Total Number Output Turns***

A decimal count of the total output turns throughout the actuator life.

#### ***Maximum Number of Starts per Hour***

The maximum number of starts per hour witnessed throughout the actuator life. This can identify if an actuator has exceeded the rated duty cycle maximum starts per hour.

### 7.12.2 Power Related Data

#### ***Number of Power Cycles***

Displays the total number of times the actuator has been powered up after a main supply loss.

#### ***Total Battery Run Time in ¼ seconds***

Displays the total time period across the actuator life that the actuator has been functioning on battery power without a main power supply. The value is shown in ¼ seconds as this is the sample rate of the data log.

#### ***Maximum Powered on Time in ¼ Seconds***

Displays the total time period across the actuator life that the actuator has been operating on the main power supply. The value is shown in ¼ seconds as this is the sample rate of the data log.

#### ***Maximum Powered Down Time in ¼ Seconds***

Displays total time period across the actuator life that the actuator has been powered off. The value is shown in ¼ seconds as this is the sample rate of the data log.

### 1.12.3 Limit Related Data

#### *Maximum Open Limit Torque Recorded*

Displays the maximum measured torque the actuator has experienced in the open direction at the open position limit.

#### *Maximum Close Limit Torque Recorded*

Displays the maximum measured torque the actuator has experienced in the close direction at the closed position limit.

### 1.12.4 Environmental Related Data

#### *Maximum Recorded Temperature*

Displays the maximum temperature (°C) recorded within the internal electronics enclosure.

#### *Minimum Recorded Temperature*

Displays the minimum temperature (°C) recorded within the internal electronics enclosure.

## 8.0 EH Pro and SI Pro Screens

The settings for EH Pro and SI Pro have been collated into one section because of the similarities present during configuration of each type of actuator. This means that some settings shown in this manual may not be visible for your specific actuator.

### 8.1 Basic Settings

- 8.1.1 Valve Tag
- 8.1.2 Close Action
- 8.1.3 Open Action
- 8.1.4 Close Pressure (Limit) (%)
- 8.1.5 Close Pressure (Mid) (%)
- 8.1.6 Open Pressure (Limit) (%)
- 8.1.7 Open Pressure (Mid) (%)
- 8.1.8 Closed Limit
- 8.1.9 Open Limit

### 8.2 Contact Relays

- 8.2.1 Contact – Function
- 8.2.2 Contact – Value
- 8.2.3 Contact – Form

### 8.3 General Settings

- 8.3.1 Remote Select
- 8.3.2 Configure Local Controls
- 8.3.3 Low Power Mode
- 8.3.4 Closed LED Colour

### 8.4 Digital Control

- 8.4.1 Remote Priority
- 8.4.2 Hold Position
- 8.4.3 Position Hysteresis
- 8.4.4 Over Pressure Hysteresis
- 8.4.5 Under Pressure Hysteresis

### 8.5 ESD/Partial Stroke

- 8.5.1 ESD
- 8.5.2 Partial Stroke
- 8.5.3 Reference Partial Stroke Test Recorded Values

### 8.6 Analogue Control

- 8.6.1 Analogue Control
- 8.6.2 Flow Characterisation

## **8.7 Interrupter Timer**

- 8.7.1 Interrupter Timer
- 8.7.2 Interrupter Timer Direction
- 8.7.3 Interrupter Timer Start (%)
- 8.7.4 Interrupter Timer Stop (%)
- 8.7.5 Interrupter Timer Interval
- 8.7.6 Interrupter Timer On Time
- 8.7.7 Interrupter Timer Off Time
- 8.7.8 Interrupter Timer with ESD Enabled

## **8.8 Actuator Statistics**

- 8.8.1 Number of Times Open Limit Reached
- 8.8.2 Number of Times Close Limit Reached
- 8.8.3 Time Spent Moving Open (sec)
- 8.8.4 Time Spent Moving Closed (sec)
- 8.8.5 Number of ESD Events
- 8.8.6 Number of Motor Starts
- 8.8.7 Number of Accumulator Recharges

## 8.1 Basic Settings

### Basic Settings

Basic settings	
Valve Tag	Test SI Pro
Close Action	<input checked="" type="radio"/> Stop on Pressure <input type="radio"/> Stop on Limit
Open Action	<input checked="" type="radio"/> Stop on Limit <input type="radio"/> Stop on Pressure
Close Pressure (Limit) (%)	<input type="range"/> 90
Close Pressure (Mid) (%)	<input type="range"/> 0
Open Pressure (Limit) (%)	<input type="range"/> 90
Open Pressure (Mid) (%)	<input type="range"/> 0
Closed Limit	0
Open Limit	4096

#### 8.1.1 Valve Tag

User defined name for the actuator consisting of up to 32 alpha-numeric or symbolic characters. It is normally used by operators to specify a unique tag based on location or a description of the actuator.

#### 8.1.2 Close Action

The actuator can be configured to close on pressure for seating valve types or limit for non-seating valve types. Limit means the actuator will stop moving once it reaches the set closed position limit. Pressure means the actuator will stop when it reaches the set closed pressure limit.

#### 8.1.3 Open Action

The actuator can be configured to open on pressure for back-seating valve types or limit for non-back seating valve types. Limit means the actuator will stop moving once it reaches the set open position limit. Pressure means the actuator will stop when it reaches the set open pressure limit.

#### 8.1.4 Close Pressure (Limit) (%)

This setting is the maximum cut-off pressure while travelling from the closed limit to the mechanical end stop. The value set is a percentage of the maximum available pressure, which is limited by the pressure relief valve.

#### 8.1.5 Close Pressure (Mid) (%)

This setting is the maximum mid-travel cut-off pressure, between the open and closed limit, while travelling in the close direction. If the value is set to 0, the pressure-off value from 8.1.7 Open Pressure is used.

#### 8.1.6 Open Pressure (Limit) (%)

This setting is the maximum cut-off pressure while travelling from the open limit to the mechanical end stop. The value set is a percentage of the maximum available pressure, which is limited by the pressure relief valve.

#### 8.1.7 Open Pressure (Mid) (%)

This setting is the maximum mid-travel cut-off pressure, between the closed and open limit, while travelling in the open direction. If the value is set to 0, the pressure-off value from 8.1.5 Close Pressure is used.

#### 8.1.8 Closed Limit

This setting shows the raw positional value for the set closed limit. Rotork Service Engineer use only.

#### 8.1.0 Open Limit

This setting shows the raw positional value for the set open limit. Rotork Service Engineer use only.

## 8.2 Contact Relays

### Contact Relays

Relay 1	
Contact r1 - Function	Closed limit
Contact r1 - Value	<input type="text" value="0"/>
Contact r1 - Form	<input type="radio"/> Normally closed <input checked="" type="radio"/> Normally open
Relay 2	
Contact r2 - Function	Open limit
Contact r2 - Value	<input type="text" value="0"/>
Contact r2 - Form	<input type="radio"/> Normally closed <input checked="" type="radio"/> Normally open
Relay 3	
Contact r3 - Function	Fault alarm
Contact r3 - Value	<input type="text" value="0"/>
Contact r3 - Form	<input type="radio"/> Normally closed <input checked="" type="radio"/> Normally open

### 8.2.1 Contact – Function

This setting determines the function of the selected relay contact. The drop down box enables the user to select from the following function settings.

Condition	Description
Closed Limit	The actuator has reached its closed limit
Open Limit	The actuator has reached its open limit
Fault Alarm	The actuator has detected a fault and is displaying an actuator alarm
Position % Open	The actuator has reached a user defined position
Motor Running	The motor is running
Closing	The actuator is moving closed
Opening	The actuator is moving open
Moving	The actuator is moving in either direction
Stall (Mid-Travel)	The motor has stalled whilst away from the limits
Stall (Any Position)	The motor has stalled whilst at either limit
Over Pressure (Mid-Travel)	The motor has stalled at any position
Over Pressure (End of Travel)	Active when an over pressure is present at either limit
Over Pressure (Any Position)	Active when an over pressure is present at any position of travel
Stop Selected	The Local/Stop/Remote switch is switched to stop
Local Selected	The Local/Stop/Remote switch is switched to Local
Remote Selected	The Local/Stop/Remote switch is switched to Remote
Control Alarm	The actuator is portraying a control alarm
ESD Active	The actuator is performing its ESD Function
Temperature (°C)	The actuator has reached a set Temperature
Manual Override Switch	Manual override is active
Accumulator Pressure Switch	Accumulator pressure has been exceeded
External Manual Reset Switch	External manual reset switch is active
Motor Thermostat Switch	Motor thermostat is active
Partial Stroke Passed	The actuator has passed its partial stroke test
Partial Stroke Failed	The actuator has failed its partial stroke test
Monitor Output	The actuator is available for remote operation
None	The relay is disabled

### 8.2.2 Contact – Value

This is directly related to some of the relay functions shown above. The setting is configurable from 0% to 100% in increments of 0.1%.

### 8.2.3 Contact – Form

Set the relay contact type to normally open (make on active) or normally closed (break on active).

## 8.3 General Settings

### General Settings

General settings	
Remote Select	Digital control
Configure Local Controls	<input checked="" type="radio"/> Push to run <input type="radio"/> Maintained
Low Power Mode	<input checked="" type="radio"/> Off <input type="radio"/> On <input type="radio"/> Extra low
Closed LED Colour	<input checked="" type="radio"/> Green <input type="radio"/> Red

#### 8.3.1 Remote Select

Specify the actuator remote control source. The available options are:

**Digital Control:** The actuator is controlled with hardwired pushbutton controls.

**Analogue Control:** The actuator is controlled using a 4-20mA or 0-10 Volt signal.

**Option Card:** The actuator is controlled using an option card over a network communication platform (e.g. Profibus, Modbus, Pakscan, Foundation Fieldbus or DeviceNet).

**Option ESD:** The actuator is controlled using an option card and a hardwired ESD function.

**Off:** There is no remote control option for the actuator.

#### 8.3.2 Configure Local Controls

Local controls can be configured to behave in two different ways.

**Push to Run:** The actuator will only move when the open or close signal is manually maintained.

**Maintained:** The actuator will self-maintain a fleeting open or close signal and will run until it reaches its respective limit or a pressure trip. The user can manually stop a maintained signal using the local controls.

#### 8.3.3 Low Power Mode

Low power mode can be activated for particular low power consumption applications. For more information on the functionality during low power states please contact Rotork. There are three available options:

**Off:** Low Power Mode is disabled and the actuator will remain powered as normal.

**On:** Low Power Mode is enabled and the actuator power consumption will decrease.

**Extra Low:** Extra Low Power Mode is enabled and the actuator power consumption will decrease to the lowest setting.

#### 8.3.4 Closed LED Colour

Set the LED colour when the actuator is at its closed limit. The open limit LED will always be the opposite colour to this setting.



## 8.4 Digital Control

### Digital Control

Digital control configuration	
Remote priority	<input checked="" type="radio"/> Stay Put <input type="radio"/> Close <input type="radio"/> Open
Hold position	<input checked="" type="radio"/> On <input type="radio"/> Off
Position hysteresis	<input type="text" value="0.5"/>
Over pressure hysteresis	<input type="text" value="10"/>
Under pressure hysteresis	<input type="text" value="10"/>

### 8.4.1 Remote Priority

Remote priority defines what the actuator will do when open and close signals are applied simultaneously. There are three available options:

**Stay Put:** The actuator will stop in the current position.

**Close:** The actuator will close until it reaches a travel limit, over pressure or manual stop.

**Open:** The actuator will open until it reaches a travel limit, over pressure or manual stop.

### 8.4.2 Hold Position

The actuator hold position setting can be configured to reduce the effects of back driving forces acting on the valve.

**On:** The actuator will maintain the current position by compensating for position drift using the solenoid valve or pump.

**Off:** The actuator position drift will not be compensated for; therefore the actual position may fluctuate.

### 8.4.3 Position Hysteresis

The position hysteresis setting works in conjunction with the hold position setting to set the amount of travel permitted before the actuator should automatically reposition itself. This is set from 0.1% to 9.9%.

### 8.4.4 Over Pressure Hysteresis

This feature will vent the internal hydraulic pressure in the actuator if it reaches a set defined value while the actuator is at a position limit. The setting range is 1% to 99%. By default this is set to 110% of the Close Pressure (Limit) 8.1.4 or Open Pressure (Limit) 8.1.6 for the respective limit position.

### 8.4.5 Under Pressure Hysteresis

This feature will increase the internal hydraulic pressure in the actuator if it falls below the set value while the actuator is at a position limit. The setting range is 1% to 99%. By default this is set to 90% of the Close Pressure (Limit) 8.1.4 or Open Pressure (Limit) 8.1.6 for the respective limit position.

## 8.5 ESD/Partial Stroke

### ESD/Partial Stroke

ESD	
Software ESD Action	De-energise all Solenoid Valves
ESD Local Stop Override	<input checked="" type="radio"/> No <input type="radio"/> Yes
ESD Contact Type	<input checked="" type="radio"/> Normally open <input type="radio"/> Normally closed
ESD Manual Reset	No Reset
ESD Temporary Loss of Signal	Stop Actuator , Move if Signal is Present
Partial stroke	
Partial stroke position (%)	<input type="range" value="90"/> 90
General Tolerance (secs)	<input type="range" value="0.5"/> 0.5
Reference Partial Stroke Test Recorded Values	
Time to Partial Stroke Position (1st Stroke)	0
Time to Partial Stroke Position (2nd Stroke)	0
Time from the Partial Stroke Position to limit (1st Stroke)	0
Time from the Partial Stroke Position to limit (2nd Stroke)	0

### 8.5.1 ESD

#### Software ESD Action

This is where the ESD action of the actuator is defined. There are four available options:

**De-energise all Solenoid Valves:** On receiving an ESD signal the actuator will de-energise all solenoid valves fitted.

**Close Actuator:** When receiving an ESD signal the actuator will run to its closed limit position.

**Open Actuator:** When receiving an ESD signal the actuator will run to its open limit position.

**Stay Put:** When receiving an ESD signal the actuator will not move from its position and stop if it is currently travelling in either direction.

#### ESD Local Stop Override

This feature dictates whether an active ESD signal will override a present local stop. There are two available options:

**No:** Select this option if a software ESD command should NOT override the local stop.

**Yes:** Select this option if a software ESD command should override a present local stop.

#### ESD Contact Type

This setting determines if a signal should be applied or removed to initiate a software ESD action. There are two available options:

**Normally Open:** The ESD signal has to be applied to perform a software ESD function.

**Normally Closed:** The ESD signal has to be removed to perform the set software ESD function.

#### ESD Manual Reset

This feature dictates the reset option for the ESD state. There are four available options:

**No Reset:** Set this option if the actuator does not need to be reset after an ESD event or loss of mains power.

**After ESD:** Set this option if the actuator must be manually reset after an ESD event.

**After Mains Loss:** Set this option if the actuator must be manually reset after loss of mains power.

**ESD/Mains Loss:** Set this option if the actuator must be manually reset after an ESD event or loss of mains power.

### ***ESD Temporary Loss of Signal***

This shows the options for the actuator under a temporary loss of an ESD signal. The available options are:

**Stop Actuator, Move if Signal is Present:** Meaning the actuator will stop and wait for the ESD signal to be restored before continuing the ESD actions

**Stop Actuator, Wait for New Signal:** Meaning the actuator will stop and wait for a new ESD signal to be sent before continuing the ESD action

**Continue ESD action:** Meaning if the signal is temporarily lost the actuator will continue to perform its ESD action.

## **8.5.2 Partial Stroke**

### ***Partial Stroke Position (%)***

This is the set position that the actuator will move to when a partial stroke test is performed. The current settings for the analogue input deadband and hysteresis values will be used during the partial stroke test. The available range is 1% to 99% at 1% increments.

### ***General Tolerance (sec)***

This is the acceptable tolerance for the partial stroke test time in addition to 8.5.3 reference strokes. E.g. with a 1.5 second tolerance and 15 second reference stroke time to total allowable time before a failure is recognised is 16.5 seconds.

## **8.5.3 Reference Partial Stroke Test Recorded Values**

The partial stroke reference test values are recorded by performing the partial stroke setup at the actuator (refer to pub021-033).

### ***Time to Partial Stroke Position (1st Stroke)***

For indication only, displays the time from the set end of travel limit, for the actuator to reach the set partial stroke position (refer to 8.5.2).

### ***Time to Partial Stroke Position (2nd Stroke)***

For indication only, displays the time from the set end of travel limit, for the actuator to reach the set partial stroke position (refer to 8.5.2).

### ***Time from the Partial Stroke Position to Limit (1st Stroke)***

For indication only, displays the time from the set partial stroke position (refer to 8.5.2), for the actuator to reach the set end of travel limit.

### ***Time from the Partial Stroke Position to Limit (2nd Stroke)***

For indication only, displays the time from the set partial stroke position (refer to 8.5.2), for the actuator to reach the set end of travel limit.

## 8.6 Analogue Control

### Analogue Control

Analogue control	
Demand Analogue Input	<input checked="" type="radio"/> Current <input type="radio"/> Voltage
Set Demand Input at Closed Limit	0
Set Demand Input at Open Limit	4096
Set CPT Output	Position Output
Analogue Signal Failure Action	<input checked="" type="radio"/> Alarm Off <input type="radio"/> Alarm On <input type="radio"/> Alarm and Softwar
Deadband Closing (%)	<input type="text" value="1"/>
Deadband Opening (%)	<input type="text" value="1"/>
Hysteresis Closing (%)	<input type="text" value="0.5"/>
Hysteresis Opening (%)	<input type="text" value="0.5"/>
Minimum percentage demand (%)	<input type="text" value="0.5"/>
Flow Characterisation	
Flow Characterisation Enabled	<input checked="" type="radio"/> No <input type="radio"/> Yes
Demand input to position at 0% (%)	<input type="text" value="0"/>
Demand input to position at 5% (%)	<input type="text" value="5"/>
Demand input to position at 10% (%)	<input type="text" value="10"/>
Demand input to position at 15% (%)	<input type="text" value="15"/>
Demand input to position at 20% (%)	<input type="text" value="20"/>
Demand input to position at 25% (%)	<input type="text" value="25"/>
Demand input to position at 30% (%)	<input type="text" value="30"/>
Demand input to position at 35% (%)	<input type="text" value="35"/>
Demand input to position at 40% (%)	<input type="text" value="40"/>
Demand input to position at 45% (%)	<input type="text" value="45"/>
Demand input to position at 50% (%)	<input type="text" value="50"/>
Demand input to position at 55% (%)	<input type="text" value="55"/>
Demand input to position at 60% (%)	<input type="text" value="60"/>
Demand input to position at 65% (%)	<input type="text" value="65"/>
Demand input to position at 70% (%)	<input type="text" value="70"/>
Demand input to position at 75% (%)	<input type="text" value="75"/>
Demand input to position at 80% (%)	<input type="text" value="80"/>
Demand input to position at 85% (%)	<input type="text" value="85"/>
Demand input to position at 90% (%)	<input type="text" value="90"/>
Demand input to position at 95% (%)	<input type="text" value="95"/>
Demand input to position at 100% (%)	<input type="text" value="100"/>

### 8.6.1 Analogue Control

#### *Demand Analogue Input*

The analogue position control can accept either a 4-20mA (current) control signal or a 0-10Vdc (voltage) control signal. This setting configures the analogue card for the appropriate control signal type.

#### *Set Demand Input at Closed Limit*

For indication only, shows the raw value witnessed by the actuator during analogue input calibration.

#### *Set Demand Input at Open Limit*

For indication only, shows the raw value witnessed by the actuator during analogue input calibration.

### ***Set CPT Output***

CPT (current position transmitter) is the analogue output signal that provides feedback of the current actuator status. There are two available options for CPT output:

**Position Output:** Displays a 4-20mA (0-10V) signal scaled to the actuator position.

4mA (0V) = 0% and 20mA (10V) = 100%.

**System Pressure:** Displays a 4-20mA (0-10V) signal scaled to the actuator system pressure.

4mA (0V) = 0% and 20mA (10V) = 100%.

### ***Analogue Signal Failure Action***

This dictates the actuator action if an analogue signal failure occurs. The three options are:

**Alarm Off:** The actuator will not present an alarm.

**Alarm On:** The actuator will present an alarm under loss of analogue signal.

**Alarm and Software ESD:** The actuator will present an alarm and perform its Software ESD action (refer to 8.5.1).

### ***Deadband Closing (%)***

This setting specifies the deadband for the analogue control signal in the close direction. The available range is 0.1% to 9.9% at 0.1% increments.

### ***Deadband Opening (%)***

This setting specifies the deadband for the analogue control signal in the open direction. The available range is 0.1% to 9.9% at 0.1% increments.

### ***Hysteresis Closing (%)***

This setting specifies the hysteresis for the analogue control signal in the close direction. The available range is 0.1% to 9.9% at 0.1% increments.

### ***Hysteresis Opening (%)***

This setting specifies the hysteresis for the analogue control signal in the open direction. The available range is 0.1% to 9.9% at 0.1% increments.

### ***Minimum Percentage Demand (%)***

The minimum demand required through the analogue input before the actuator will move away from the closed limit. The available range is 0% to 9.9% at 0.1% increments.

## **8.6.2 Flow Characterisation**

### ***Flow Characterisation Enabled***

This enables or disables flow characterisation. The analogue input for the SI Pro can be characterised to suit the valve type. For example, equal percentage flow can be configured for the analogue input.

### ***Demand input to position at (0% - 100%)***

Each setting relates to an actuator position, every 5% across the full range of travel. The editable setting value relates to a percentage of the analogue signal span (0% is 4mA or 0Vdc, 100% is 20mA or 10Vdc).

## 8.7 Interrupter Timer

The Interrupter Timer is designed to increase the valve operating time by periodically inhibiting movement of the unit. This can be used to reduce the effects of hydraulic shock “water hammer” in the process pipeline.

### Interrupter Timer

Interrupter Timer		
Interrupter Timer	<input checked="" type="radio"/> Disabled	<input type="radio"/> Enabled
Interrupter Timer Direction	<input checked="" type="radio"/> Closing	<input type="radio"/> Opening
Interrupter Timer Start (%)	[-] [Slider] [+ 1]	
Interrupter Timer Stop (%)	[-] [Slider] [+ 1]	
Interrupter Timer Interval	<input checked="" type="radio"/> Seconds	<input type="radio"/> Milliseconds
Interrupter Timer On Time	[-] [Slider] [+ 50]	
Interrupter Timer Off Time	[-] [Slider] [+ 50]	
Interrupter Timer with ESD Enabled	<input checked="" type="radio"/> No	<input type="radio"/> Yes

### 8.7.1 Interrupter Timer

Enable or disable the Interrupter Timer function.

### 8.7.2 Interrupter Timer Direction

This setting dictates which direction the Interrupter Timer will function.

**Closing:** The Interrupter Timer will only be active in the close direction.

**Opening:** The Interrupter Timer will only be active in the open direction.

### 8.7.3 Interrupter Timer Start (%)

Specify the valve position that timed operation will begin, the available range is 0% to 100% at 1% increments.

### 8.7.4 Interrupter Timer Stop (%)

Specify the valve position that timed operation will stop, the available range is 0% to 100% at 1% increments.

### 8.7.5 Interrupter Timer Interval

Specify the setting units for the Interrupter Timer on and off times. The available options are:

**Seconds:** The values associated to 8.7.6 and 8.7.7 will be in seconds.

**Milliseconds:** The values associated to 8.7.6 and 8.7.7 will be in milliseconds.

### 8.7.6 Interrupter Timer On Time

The set time for the movement period during timed operation. Configurable from 1 to 99.

### 8.7.7 Interrupter Timer Off Time

The set time for the inhibited period during timed operation. Configurable from 1 to 99.

### 8.7.8 Interrupter Timer with ESD Enabled

This setting will enable or disable the Interrupter Timer during an ESD action.

**No:** The ESD action will override the Interrupter Timer and operate at full actuator speed.

**Yes:** The ESD action will operate with the Interrupter Timer settings inhibiting movement.

## 8.8 Actuator Statistics

### Actuator Statistics

Actuator Statistics	
Number of Times Open Limit Reached	0
Number of Times Close Limit Reached	0
Time Spent Moving Open (sec)	8
Time Spent Moving Closed (sec)	11
Number of ESD Events	0
Number of Motor Starts	0
Number of Accumulator Recharges	0

#### 8.8.1 Number of Times Open Limit Reached

For indication only, shows the number of times the actuator has reached its open limit.

#### 8.8.2 Number of Times Close Limit Reached

For indication only, shows the number of times the actuator has reached its closed limit.

#### 8.8.3 Time Spent Moving Open (sec)

For indication only, shows the time the actuator has spent moving in the open direction.

#### 8.8.4 Time Spent Moving Closed (sec)

For indication only, shows the time the actuator has spent moving in the closed direction.

#### 8.8.5 Number of ESD Events

For indication only, shows the number of ESD events that have occurred.

#### 8.8.6 Number of Motor Starts

For indication only, shows the number of motor starts experienced by the actuator.

#### 8.8.7 Number of Accumulator Recharges

For indication only, shows the number of times the accumulator has been recharged.

## 9.0 Bluetooth Setting Tool Screens

### 9.1 BTST Information

- 9.1.1 Firmware Version
- 9.1.2 Battery Status (mV)
- 9.1.3 Number of Files
- 9.1.4 Free Space on the BTST (Bytes)
- 9.1.5 Flash Memory Size on BTST (Bytes)

### 9.2 CVA

### 9.3 IQ2

### 9.4 EHP

### 9.5 IQ3

### 9.6 SIP

### 9.7 Missions

- 9.7.1 Create Missions
- 9.7.2 Custom Mission
- 9.7.3 Review/Edit Mission
- 9.7.4 Delete Mission
- 9.7.5 Delete All Missions
- 9.7.6 Format BST

To connect to the *Bluetooth* Setting Tool Pro please refer to section 4.3 of this manual.

### 9.1 BTST Information

This screen is found by clicking on the *Bluetooth* Setting Tool in Insight 2.

#### 9.1.1 Firmware Version

Shows the firmware version of the connected *Bluetooth* Setting Tool.

#### 9.1.2 Battery Status (mV)

Shows the battery status of the connected *Bluetooth* Setting Tool.

#### 9.1.3 Number of Files

Shows the number of files stored on the *Bluetooth* Setting Tool. This includes configuration, data log and mission files but excludes any system files used for *Bluetooth* communication.

#### 9.1.4 Free Space on the BTST (Bytes)

Shows the remaining space left on the *Bluetooth* Setting Tool.

#### 9.1.5 Flash Memory size on BTST (Bytes)

Shows the capacity of the *Bluetooth* Setting Tool.

### 9.2 CVA

This is where configuration and data log files for CVA actuators are stored. They are stored under their individual serial numbers. Double clicking a serial number will open the stored configuration file and associated data log. For information on all CVA Screen see section 5.0 CVA and CVA Quarter Turn Screens.



### 9.3 IQ2

This feature is currently unavailable but will be introduced in a future version of Insight 2. Support for our IQ2 range of actuators is through the first iteration of Insight.

### 9.4 EHP

This is where configuration and data log files for EH Pro Actuators are stored. They are stored under their individual serial numbers. Double clicking a serial number will open the stored configuration file and associated data log. For information on all EH Pro Screens see section 7.0 EH Pro and SI Pro Screens.

### 9.5 IQ3

This is where configuration and data log files for IQ3 actuators are stored. They are stored under their individual serial numbers. Double clicking a serial number will open the stored configuration file and associated data log. For information on all IQ3 Screens see section 6.0 – IQ3 Screens.

### 9.6 SIP


This is where configuration and data log files for SI Pro Actuators are stored. They are stored under their individual serial numbers. Double clicking a serial number will open the stored configuration file and associated data log. For information on all SI Pro Screens see section 7.0 EH Pro and SI Pro Screens.

### 9.7 Missions


A mission is a defined set of instructions programmed to perform a variety of tasks when communicating with an actuator. Missions are used to send and receive actuator configuration files, upload firmware and collect data log files.

#### 9.7.1 Create Missions


To create a mission, right click on the missions menu under *Bluetooth* Setting Tool.




From here the Setup Mission screen will appear and you can start to create your mission.





Here you can select the mission type from the drop down menu.



For Missions which upload firmware or configuration files, the browse button can be used to find the file necessary for the upload. Select the appropriate actuator type from the list as shown below.




If the mission is intended for a specific actuator, the serial number can be entered in the Serial Number field. If the connected actuator does not match the entered serial number then the mission will be skipped. If the mission is intended for all actuators that satisfy the actuator type criteria, select “Send to All” on the right hand side of the Serial Number field.



Depending upon the type of mission, Insight 2 will require you to input the corresponding actuator privilege level password. The required privilege level will be shown in brackets.


**Note: If the wrong password is entered, the mission will still write to the setting tool however it will fail when you attempt to run it once connected to an actuator.**



When all the mission details are complete, select “Done” and wait for it to be uploaded to the setting tool.

### 9.7.2 Custom Mission

Custom Missions can be used to configure more complicated settings in a Rotork actuator. To add a custom mission file to the *Bluetooth* setting tool right click on the Missions menu and select Load Custom Mission File. The window below will appear allowing the user to browse for the custom mission file they wish to load.




Alternatively create a new mission and select Custom Mission File from the drop down mission type menu or right click the setting tool name and select “LoadMissionFile”.

### 9.7.3 Review/Edit Mission

To review/edit a mission on the *Bluetooth* setting tool the user must right click on the mission they wish to edit and select the Review/Edit Mission option from the drop down menu.


This will bring up the screen below and allow the user to change all the mission settings.




### 9.7.4 Delete Mission

To remove a mission from the setting tool, just right click on the mission and click Delete Mission.

### 9.7.5 Delete All Missions



To delete all missions currently present on the *Bluetooth* Setting Tool, right click the setting tool tag and select Delete All Missions. A confirmation window will appear before you can continue. This function will only delete mission files. Any configuration or data log files currently held in memory will remain on the tool.



### 9.7.6 Format BST

To format the *Bluetooth* Setting Tool Pro to the factory default state, right click the setting tool name and select Format BST. Formatting the setting tool will remove all missions, configurations and data log files currently held in memory.

