


**SPARE PARTS LIST FOR RANGE OF IR3.5 INPUT REDUCERS**



**EXPLODED VIEW FOR IR3.5 INPUT REDUCER**

ITEM	DESCRIPTION	QUANTITY
*1	BEARING RETAINER	1
*2	BEARING	1
*3	BEARING	4
*4	BEARING	2
*5	BEARING	1
6	BEARING	1
7	BEARING SUPPORT RING	1
8	CIRCLIP	1
9	CIRCLIP	1
10	ENDPLATE	1
11	GEARCASE	1
12	GEARSHAFT	1
13	GREASE	
14	INPUT FLANGE	1
15	INPUT GEAR	1
16	INPUT SHAFT AND GEAR	1
17	KEY	1

18	KEY	1
19	NORDLOCK WASHER	8
20	NORDLOCK WASHER	4
21	NORDLOCK WASHER	8
*22	O-RING	1
*23	O-RING	1
24	OUTPUT GEAR	1
25	SCREW	4
26	SCREW	8
27	SCREW	8
28	SPACER	1
29	SPACER	1

Note: Items marked \* are the recommended spares holding for 5 years operation