

In order to update the ADF file, you must run the Insight 2 program as an administrator. If you do not currently have administrator rights on your PC, please consult you IT department. Once admin right have been established you need to navigate to the APP.EXE file in the following directory:

C:\Program Files (x86)\Rotork Controls\Insight 2\Components

Right click the APP.EXE file and select 'Run as Administrator'

	Open
	Enable/Disable Digital Signature Icons
0	Run as administrator
	Troubleshoot compatibility
	Run with graphics processor
	7-Zip
Ð	Scan with System Center Endpoint Protection
,,,,,	Add to archive
,,,,	Add to "App.rar"
()))	Compress and email
,,,,	Compress to "App.rar" and email
	Pin to Taskbar
	Pin to Start Menu
	Restore previous versions
	Send to
	Cut
	Сору
	Create shortcut
	Delete
	Rename
	Properties

Log into Insight 2 using the USER password – ROTORK Navigate to the TOOLS \rightarrow INSTALL ACTUATOR DEVICES

Insight 2		
File Connection Security → → ↓ ↓ ↓	Tools Help Sensor Calibration	
OFFLINE BLUETOOTH	Zero Thrust CP Chat	rotory
	Unit Setting Install Actuator Devices	IULUIK
fine	11	Deight 2 Login : Administrator

Locate the ADF files (ZIP format) and click install

uator Definiti	on File Installer
Select valid zi	ip file having Actuator Devices to be installed:
Browse	\\rotork.co.uk\files\GB-BATH\GB-BATH_DOCUMENTS\steve

Once complete, the following message will be displayed



 Brassmill Lane

 Bath

 BA1 3JQ

 tel
 +44 (0) 1225 733200

 fax
 + 44 (0) 1225 333467

 email
 mail@rotork.com