


CIRCUIT DRAWN WITH
POWER SUPPLY OFF



TRANSFORMER TAPPING

NOM 50/60HZ	50HZ	60HZ
110/120	92-135	92-135
220/230	176-242	176-242

FS1 - See ROMPAK PUB008-006 Installation and Maintenance Manual

NOTE

FOR TYPICAL REMOTE CONTROL INDICATING, MONITORING AND ALARM CIRCUITS SEE PUBLICATION DOC862

MAX EXTERNAL LOAD ON S1/S2 RELAYS TO BE 5A. MAX VOLTAGE 120V AC/DC

MAX EXTERNAL LOAD ON TERMINAL 27 & 28 TO BE 3W

CONTROL SIGNAL THRESHOLD VOLTAGES:

MAX 60V DC
TO BE MINIMUM 'ON' 14V DC AT 1mA
MAXIMUM 'OFF' = 3V

MINIMUM CONTROL SIGNAL DURATION TO BE 300mS.

CURRENT DRAWN FROM EACH REMOTE CONTROL SIGNAL IS 5mA ON 24V DC

LS3 / LS4
MAXIMUM CURRENT 3A MAXIMUM VOLTAGE 120V AC/DC

VOLTAGE SELECT SWITCH SW1, MUST BE CONFIGURED CORRECTLY BEFORE APPLYING POWER.

ACTUATOR CONFIGURATION VIA DIL SWITCH SW2

REFER TO INSTALLATION INSTRUCTIONS FOR DIL SWITCH SELECTION

Iss	Date	Chkd	Revision Details
1	170414		First Issue

www.rotork.com

ROTORK CONTROLS LTD
BATH, BA1 3JQ
ENGLAND
Tel:01225-733200

ROTORK CONTROLS INC
ROCHESTER
NY 14624, USA
Tel:585-247-2304

ROMPAK 1PH - NO TORQUE SWITCHES + FOUNDATION FIELDBUS

Drawn by: VYA
Date : 17-Apr-14
Base WD: R201-800
Job No : - -
MI No : - -

Circuit Diagram No
R201-800
Issue No
1