


CIRCUIT DRAWN WITH POWER SUPPLY OFF



FOR TYPICAL REMOTE CONTROL DETAILS SEE DOCUMENT No RWS

TRANSFORMER TAPPING OPTIONS


TYPE 1			TYPE 2		
TAP	NOM	RANGE	TAP	NOM	RANGE
X	100	80-120	X	200	160-240
Y	110	88-132	Y	230	184-276
Z	120	96-144	Z	270	216-324
FS1-250mA A/S FS2-5A A/S			FS1-150mA A/S FS2-2.5A A/S		

TYPE 3			TYPE 4		
TAP	NOM	RANGE	TAP	NOM	RANGE
X	380	304-456	X	480	384-576
Y	400	320-480	Y	575	460-690
Z	415	332-498	Z	690	552-828
FS1-100mA A/S FS2-1.5A A/S			FS1-50mA A/S FS2-1.6A F/A		

TRANSFORMER TYPES 1, 2, 3 & 4 - FUSE FS3 - 20A ATO FAST ACTING

TYPE 5 24VDC



ALL TRANSFORMER TYPES - PS1 SELF RESETTING FUSE

**NOTE**  
REFER TO PUBLICATION E175E FOR APPROVED FUSES FS1, FS2 AND FS3.  
MAX EXTERNAL LOAD ON TERMINALS 4 & 5 TO BE 5W.  
CONTROL SIGNAL THRESHOLD VOLTAGES TO BE MINIMUM 'ON' 20V DC  
MAXIMUM 'OFF' = 3V  
MINIMUM CONTROL SIGNAL DURATION TO BE 100mS.

CURRENT DRAWN FROM EACH REMOTE CONTROL SIGNAL IS 5mA ON 24V DC  
WIRES ARE IDENTIFIED AT EACH END BY TERMINAL No. OR TAG No.

VOLTAGE INPUT (0-5 VOLTS)  
+Ve TO 'A', 0 VOLTS TO COMMON  
CURRENT INPUT (0-20mA)  
LINK A TO B, CURRENT SOURCE BETWEEN A/B AND COMMON.  
ANALOGUE I/P 'A'  
ANALOGUE I/P 'B'  
COMMON  
TERMINATOR TO USE THE TERMINATOR CONNECT A LINK BETWEEN THE TERMINATOR AND 1B BUNG CONNECTIONS. WIRE MODBUS FIELD CONNECTIONS AS NORMAL.  
COMMON  
SCREEN

INDICATION CONTACTS S1-S4 ARE SHOWN IN THEIR DEFAULT CONFIGURATION. CONTACTS MAY BE CONFIGURED FOR ANY OF THE FUNCTIONS DESCRIBED IN E175E

No	DATE	REVISION DETAILS
02	180107	IQPRO MODBUS UPDATE EC2197/3

**www.rotork.com**

ROTORK CONTROLS LTD  
BATH, BA1 3JQ  
ENGLAND  
Tel: 01225-733200

ROTORK CONTROLS INC  
ROCHESTER  
NY 14624, USA  
Tel: 585-328-1550

CONFIG BY PJW  
DATE 151003  
CHECKED DA  
BASE WD 7000-400  
JOB No -  
M.I.No -

IQTM + MODBUS MODULE

CIRCUIT DIAGRAM No -REV 107  
**7000-400-02**

B1 C1 B2 C2